ACCELERATOR DIVISION DEPARTMENTAL PROCEDURE

ACCELERATOR OPERATIONS DEPARTMENT

ADDP-OP-0003

CRYOGENIC EMERGENCY RESPONSE PROCEDURE

MCR

PREPARED BY	Joe Compton AD Operations Department	DATE _	5/19/23	-
APPROVED BY	Told Alleria	DATE	05/19/2023	
	Todd Sullivan AD Operations Department Ho			

REVISION ISSUE DATE <u>5/18/2023</u>

REVISION NO. 1

REVIEW AND CONCURRENCE RECORD

REVIEWED BY Raymond Lewis DATE 5-19-2023

Acting ES&H AD Division Safety Officer

Author	Description of Change	Revision Date		
Joe Compton	Removed sections 3.1.6 and 3.1.7	5/18/2023		
	Added AC Master and enclosure (if			
	needed) key to 3.1.1			
	Removed note from 3.1.5			
	Updated flow chart for above changes.			
	Added section 3.1.4			
Joe Compton	Updated for the required procedure format.	4/13/2023		
-	Added Attachment 1 flow chart.			

1.0	PURPOSE AND SCOPE1
2.0	RESPONSIBILITIES1
3.0	INSTRUCTIONS1
4.0	DISTRIBUTION2
	CHMENT 1: CRYOGENIC EMERGENCY RESPONSE PROCEDURE – MCR

1.0 PURPOSE AND SCOPE

The purpose of this Accelerator Division Departmental Procedure (ADDP) is to establish and define the Fermilab Accelerator Division Operations Department Main Control Room (MCR) response to a report of a Cryogenic Emergency.

2.0 **RESPONSIBILITIES**

- 2.1 Crew Chief or designee shall initiate response by following the included instructions.
- 2.2 Operators in the MCR shall follow the following included instructions.

3.0 INSTRUCTIONS

- 3.1 Upon report of a Cryogenic emergency, the MCR shall follow the following instructions.
- 3.1.1 The Crew Chief or designee shall ensure that the Security Operation Center (emergency dispatch) has been notified (which may require calling x3131).
- 3.1.2 Dispatch a Field Team with a hand held radio, AC3, AC master, and appropriate enclosure (if needed) keys, and oxygen monitors to meet with the Fermilab Fire Department (FFD).

Note: The Incident Commander may request that an expert, who is familiar with the area, enter the building/enclosure to help with the investigation. The expert who enters the building/enclosure will be escorted by the Fire Department at all times.

- 3.1.3 Evacuate the area via intercom if possible.
- 3.1.4 Contact the Cryo Coordinator (use the MCR Call-in list at https://www-bd.fnal.gov/cgi-mcr/callin.pl if necessary) and the Division Safety Officer (DSO).
- 3.1.5 Obtain a list of personnel who have been issued an AC3 or enclosure keys to the affected area, if applicable. Relay the list to the field team.
- 3.1.6 Gather information from the Field Team to relay to Cryo experts.
- 3.1.7 Document all relevant oxygen readings and data logger plots in the MCR Electronic Elog (E-log).


CONTROLLED DOCUMENT

Note: Attachment 1: Cryogenic Emergency Response Procedure- MCR is attached to this procedure which contains a flow chart of this procedure for reference.

4.0 **DISTRIBUTION**

4.1 An electronic controlled copy of this procedure is maintained on the AD Operations website at: https://operations.fnal.gov/ops/addp.html.

Cryogenic Emergency Response Procedure - MCR



			E