

# LArIAT All Experimenters' Meeting 2016.07.11

Jason St. John U of Cincinnati


#### **Proton Usage**









## **Computing Usage**




July began with questionable LAr purity: Some tracks attenuated, some robust



Within days, more and more tracks showed evidence of a worsening problem



We ran a purity estimation job for several key days. Lifetime recovered once, but can it do it again?




Lifetime wasn't too great even right after regeneration.

There is reason to suspect the dip was due to a LAr delivery with high  $O_2$  concentration.


We are now headed even lower. Want to understand why.

Using assays (for ppm  $O_2$  estimates) and delivery tickets (for delivered quantity LAr) we can estimate a lower limit of how much  $O_2$  the filter has been seeing



High-O<sub>2</sub> deliveries (~1 ppm) happened a few times.

Using assavs (for nom O estimates) and delivery tickets (for delivered quantity LAr)




O<sub>2</sub> the filter has been seeing

High-O<sub>2</sub> deliveries (~1 ppm) precede declines in lifetime.

System was recovering... then during E-field studies, we hit it again with some funky LAr, unfortunately.

Using assays (for ppm  $O_2$  estimates) and delivery tickets (for delivered quantity LAr) we can estimate a lower limit of how much  $O_2$  the filter has been seeing



The estimated filter capacity is  $\sim 17 \, \mathrm{g} \, \mathrm{O}_2$ . Might be there in the next week, and things are already not good.

So July 6 we decided to initiate regeneration proceedings.

#### The LAr Purity - The Plan now

Monitoring and prevention of further incidents:

- We had two O2 gas analyzers monitoring the cryostat (liquid & ullage)
- July 6 moved one to monitor storage dewar ullage
- Fritz Schwartz & company working to borrow very sensitive model, to put downstream of filter. Cryo Controls group to help read them out.

July 7: Cut off flow to filter, begin emptying & warming for regeneration

- Shut off cathode, wires, cryoPMTs, wire chambers HV & gas.

July 8: Bring regeneration gas (Ar w/ H<sub>2</sub>) tube trailer to MCenter

July 11 Monday: Heat filter and slowly introduce  $H_2$ , initiating rxn with adsorbed  $O_2$ .

July 12 Tuesday: Complete regeneration reaction if possible

When regenerated: Chill & fill.

Wednesday/Thursday Evening: Resume operations!