



## LArIAT Light Collection System

Andrzej Szelc,

Manchester

(for the LArIAT collaboration)







#### LArIAT



A test facility to calibrate and test LArTPCs and their components using a beam of charged particles and a test-beam experiment.


Reusing the ArgoNeuT detector with small modifications:

- front flange modified with excluder
  - + Titanium window.
- Side flange modified to allow for Light System.
- Bottom flange modified to enable liquid recirculation (quicker purification).

Run 1 completed.
Run 2 completed.
Run 3 ongoing.

More details in Andrea Falcone's Talk







### **LArIAT Light Readout**



LArIAT is an excellent test-bed for new ideas.

The light collection system is designed to maximize efficiency of collection.


Uses WLS – covered

Hamamatsu

R11065

foils.

First test of TPB coated reflector foils in a running TPC (at beam neutrino energies).




Two cryogenic PMTS


- one 3" high QE (30%)

- one 2" standard QE (20%)

+3 SiPMs

**Wavelength shifting** reflector foil







D757KFL (2")




## **Light Collection System**



- Choice of PMTs limited by size of side flange.
- Digitized using CAEN V1751, 1GS/s digitizer able to resolve single phel.








## **Example Waveforms**




OpDet0: run 10134, subrun 1, event 9738






## **Example Waveforms**






PMT calibration performed in-situ on tails of LAr scintillation events.

Single phel counting to obtain full light spectrum.







## **Triggers**



- Can use combination of triggers.
  - LARSCINT trigger on amplified ETL signal (-12 mV)
  - MICHEL catch Michel electrons/positrons (=next slides)
  - SCINTGATE (400 us gate after each LARSCINT)
  - LARRY: muon "telescope"
    - Coincidence of LARSCINT with either of upper cosmic paddles.
    - Catches both through going and stopping muons.










## Measuring N<sub>2</sub> contamination




## using light



Results agree with measurements using gas analyzers.

N<sub>2</sub> contamination can be understood using the slow component of the argon scintillation light






# Light Collection Uniformity



 Using LArSoft Simulation tools developed to account for optical foils (checked by standalone code) to model detector response.



Good uniformity in the detector.

Enables new uses of scintillation light.


W. Foreman






## Validating the Simulation

- Simplest topology easy to understand.
- Great to test predictions vs reality.
- Data agrees with MC predictions (check in subsections of the detector in progress).









#### Michel Electrons



$$\mu^{+/-}$$
 (at rest)  $\rightarrow e^{+/-} + \nu_{\mu} + \overline{\nu}_{e}$ 

- Well known energy spectrum.
- Great to perform calibrations.
- Need scintillation light to trigger.






Real-time triggering on Michel e's from stopping cosmic µ's using **light signals** 

W. Foreman



## Energy Calibration with Michels





- Michel-candidate signals integrated to get PE spectrum
- MC reproduces shape well.
   Gives more confidence in simulation model.
- LY compatible with throughgoing muons.
- Uniformity greatly helps.

End goal: combine charge + light to get full energy reconstruction.

W. Foreman



## Physics with Michels



The University of Manchester


μ<sup>-</sup> have a predicted 75% capture rate on argon nuclei (no Michel electron present).

$$au_{\mu-} = \left(\frac{1}{ au_c} + \frac{Q}{ au_{free}}\right)^{-1}$$
650 ± 52 ns
(from fit result, preliminary)
918 ± 109 ns

Early results agree w/ recent measurement<sup>1</sup> (854 ± 13 ns) and theory prediction<sup>2</sup> (851ns)

<sup>1</sup>(Klinskih et al., 2008) <sup>2</sup>(Suzuki & Measday, 1987)

15/05/17









- Use dichroic filters + 2 WLS
- Readout 1 SiPM, with a larger active surface.

Plans to install in protoDUNE and SBND











### **Current Run**




- Installed one ARAPUCA detector.
- Able to compare response with PMTs in-situ.







## MANCHESTER Mesh cathode





Prototype of SBND-like mesh cathode was installed in LArIAT beginning of march. Will run with and without foils (change over in a couple of weeks).

500 LBS CAPACITY



## **Evaporating foils**



- The infrastructure needed to manufacture the reflective foils is ready.
- New LArIAT foils will be made this week.
- Will improve ongoing analysis of "late light" in argon.





## Coming Soon:

Stay tuned for other analyses using scintillation light:

- Particle ID using scintillation light + charge.
- More calorimetry using scintillation light.
- Late light studies.
- Comparison of SiPM, ARAPUCA and PMT performance with data.



#### MANCHESTER 1824

## Summary




- LArIAT light collection system is a new approach (at these energies).
- High LY enables diagnostic uses of scintillation light.
- Enhanced uniformity enables calorimetric studies and muon sign discrimination.
- LArIAT analyses on using light and combined light + charge for calorimetry, particle ID are close to completion.
- Stay tuned for results from LArIAT run III and previous data!




# Thank You for your Attention










## Fermilab Testbeam Facility



The LArIAT testbeam experiment is running in MCenter – allows long term occupation (as opposed to MTest).


Main Injector
One 4s long spill per minute
Secondary beam
max 300k particles/spill



#### **LArIAT Beamline**

· artiole momentum (me rio)









### LArIAT Beamline







### **Beamline Elements**







MWPCs

Magnets + TOFs + MWPC allow reconstructing momentum and PID of particles in the tertiary beam.

TOFs

Controlled sample of particles hitting the TPC.







# $\mu$ vs $\pi$ separation in beamline








Aerogel Cherenkov counters for further PID  $\pi$  vs.  $\mu$  discrimination

Effective for TPC-contained  $\pi/\mu$  range: 230-400 MeV/c


n=1.11 n=1.057 Aerogel

200-300 MeV/c  $\mu \pi$   $\mu \pi$ 300-400 MeV/c  $\mu \pi$   $\mu \pi$ 




## Time Projection Chamber











## MANCHESTER Kaon ID and reconstruction







- Kaon-argon interaction cross section measurement
- Understand kaon/pion and kaon/proton discrimination
- Important for proton decay searches in future experiments

## Muon charge-sign discrimination



- Argon Nuclei have a 75% chance to capture muons. They never capture anti-muons.
- This results in different topologies.
- In case the topologies are the same: different effective decay times.
- Can determine flux composition statistically (and in some cases on an event-by-event basis).






W. Foreman, UChi



### Study of p events in LAr






#### Antiproton Star Observed in Emulsion\*

O. CHAMBERLAIN, W. W. CHUPP, G. GOLDHABER, E. SEGRÈ, AND C. Wiegand, Radiation Laboratory, Department of Physics, University of California, Berkeley, California

ANI

E. AMALDI, G. BARONI, C. CASTAGNOLI, C. FRANZINETTI, AND A. MANFREDINI, Istituto di Fisica della Università, Roma Istituto Nazionale di Fisica Nucleare,

Sezione di Roma, Italy



Low momentum anti-protons in the beam (even at a small rate) will allow the first study of hadron star topology from p-p annihilation at rest in Argon


- $\pi^{\pm}$ ,  $\pi^{0}$ ,  $K^{\pm}$ , etc.. multiplicity in hadron stars can be accurately determined utilizing LAr imaging detector capabilities.
- This information is very relevant for n-n oscillation searches at future large underground LArTPC detectors.


MANCHESTER Electron / shower separation


LArIAT, can see electrons in the beamline.

The number of photons can be increased by adding a pre-shower disk (1X<sub>0</sub>) width

Should give larger and possibly cleaner samples of events compared to **ArgoNeuT** 







15/05/17

A. M. Szelc



## $\pi$ -argon cross sections






FIG. 9. Decomposition of the total  $\pi^*$ -nucleus cross section at 165 MeV. The lines are least squares fits to power laws.

No measurements for <sup>40</sup>Ar (yet!)

Predictions come from interpolation between heavier/lighter nuclei

LArIAT analysis goals: Total interaction cross section Exclusive interaction channels:

Absorption
Charge exchange
Inelastic & elastic scattering

LArIAT has measured the total pion interaction cross-section





#### Total $\pi$ -Ar cross-section



 $\sigma_{\text{Total}}\!=\!\sigma_{\text{elastic}}\!+\!\sigma_{\text{inelastic}}\!+\!\sigma_{\text{ch-exch}}\!+\!\sigma_{\text{absorp.}}\!+\!\sigma_{\pi\text{-production}}$ 

A multitude of topologies








#### Total $\pi$ -Ar cross-section



$$\sigma_{\text{Total}} = \sigma_{\text{elastic}} + \sigma_{\text{inelastic}} + \sigma_{\text{ch-exch}} + \sigma_{\text{absorp.}} + \sigma_{\pi \text{-production}}$$


- First
   measurement
   of pion
   interaction on
   argon
- Analysis of Exclusive channels in progress.






MANCHESTER 1824

## Effects of nitrogen contamination on argon scintillation




## Scintillation Light in Argon

#### **Emission:**



Photons are all ~128 nm - VUV

Light consists of two components: fast and slow. Their relative amplitudes depend on ionization density (theory).



(practice) the shape can be affected by transport, contamination and WLS effects (next slides)

## Scintillation Light in Argon (2)


#### **Transport:**

Liquid argon is mostly transparent to its own scintillation.

At longer distances effects like:

- Rayleigh scattering ~55cm  $f(\lambda)$
- absorption, e.g. on nitrogen ~30 m @2ppm N2 begin to play a role.

Note high refractive index ~1.5 and gradient of for VUV → relatively slow light.



Y


## Scintillation Light in Argon (3)

#### **Detection:**

Liquid argon is almost the **only** thing transparent to its scintillation.

Detection is challenging – most often need to use Wavelength shifting compounds, like TPB.

Can deposit WLS on Light detection components or inside the detector.



VUV sensitive SiPMs prototypes have appeared very recently.

