Evolution of Electron Beam (E-Beam) Treatment for Water



Workshop on Application of Electron Beam (EB) Technology on WW & Biosolids Treatment May 10-11, 2018, FermiLab



Collaborators

Joan B. Rose, Michigan State University Bill Cooper, University of California, Irvine Regina Sommer, University of Vienna Michael G. Nickelsen, Haley & Aldrich, Inc. Kimberly Kunihiro, Orange County Utilities







What is an "E-Beam"?

Most of us (used to) have one or more in our home!

Conventional CRT computer monitors or televisions

Electron Gun → Accelerator emits electrons @ 25,000 Volts

Scanned to create images



http://en.wikipedia.org/wiki/File:Egun.jpg

Thermionic electron gun assembly found on a color Samsung CRT monitor. The gun produces three high speed individual electron beams for the three primary colors (Red, Green, and Blue)



E-beam Workshop at FermiLab, May 2018

www.e-wastesolutions.net


E-Beam for Water Treatment

Accelerator → Electrons @ 500,000 to 1,500,000 volts (75 kW or more) scanned to penetrate water or vapor.



E-beam Workshop at FermiLab, May 2018

The Electromagnetic Spectrum



http://www.scienceinschool.org/2011/issue20/em (ESA/AOES Medialab)

Some Common Irradiation Uses

• Foods:

- Insect control
- Inhibits sprouting
- Controls mold
- Inactivates pathogens (e.g. E. coli, norovirus, Trichina parasite, etc.)
- Increases shelf life

Sterilization:

- Medical supplies & packaging
- Hospital waste
- Blood and tissues for transfusions

• Materials Processing:

- Composite materials curing
- Crosslinking
- Semi conductor enhancement



www.NPR.org Lui Kit Wong/MCT /Landov

Not irradiated




http://www.globalpeace.go.jp/en/qfile/ao7.html
Photo provided by the Shihorocho Agricultural
Cooperative Isotope Irradiation Center




http://www.arserrc.gov/www/fsit/FoodIrradiation.htm

Industrial Applications of E-Beam Sterilization



Source: tactic-tech.com via: http://www.homelandsecuritynewswire.com/dr20120408-ebeam-technology-to-keep-food-supply-safe


Configuration of e-beam Wastewater Treatment





Virginia Key WWTP (Miami, FL) Large Scale Studies







Virginia Key E-Beam Demonstration Scale Pilot Plant





Diagram of the Electron Beam Scanner and Weir Assembly

Electron Beam Research Facility at the Austrian Research Center, Seibersdorf, Austria

- Bench scale flow through system
- Flowing aqueous stream (3 m³/hr)
- 500 kV, 25 mA, scan width 1.2 m (High Voltage Engineering, USA)
- 400 up to 2000 Gy/s
- Enabled *Cryptosporidium* inactivation studies
- City of Vienna, Austria unchlorinated tap water

Mobile E-Beam System: High Voltage Environmental Applications, Inc.





Recycled water treated for aquifer storage & Recovery must meet "Full Treatment" defined under Florida Administrative Code 62-610

Orange County E-Beam Pilot Testing

- **Unchlorinated Reclaimed Water (Site 1)**
- **UF Permeate (Site 2)**
- **RO Permeate (Site 4)**
- **UF/RO Membrane Concentrate (Site 6)**





E-beam Workshop at FermiLab, May 2018


Advanced Oxidation Processes (AOPs)

- AOPs are organic contaminant destruction processes.
- Rely on *in-situ* formation of hydroxyl radicals: •OH
- Involve two stages of oxidation:
 - Formation of the strong oxidants (e.g. •OH)
 - Reaction of the oxidants with organic contaminants
- Provide a barrier to both microbial and chemical contamination
 - One process = multiple benefits & barriers
 - Effectively reduces/removes low concentrations of organic chemicals


Some Advanced Oxidation Processes

AOP	In-situ generated radical species
Electron Beam	•OH (oxidizer) •H (both oxidizer & reducer) e-aq (reducer)
Ozone/H2O2	•OH
TiO2/UV light	e- _{aq} H+
Fenton's chemistry (Fe(II)/H2O2)	•OH
Sonolysis	•OH •H
UV/H2O2	•OH

Water Radiolysis: Formation of Free Radical Species in Water by Means of Ionizing Radiation





Simplified Model of the Competition for the Free Radical Species in a Natural Groundwater



E-Beam Disinfection Mechanism

- Direct effects are extremely rapid (10⁻¹⁶ seconds)
- Induced through energy deposition at sensitive target sites, typically vital sub-cellular components:
 - Enzymes
 - Nucleic acids
 - Genetic material






International Topical Meeting on Nuclear Research Applications and Utilization of Accelerators, Vienna, Austria 2009. Eb-Tech, Daejeon 305-500, Korea


Irradiated foods, materials, water, etc., do not become radioactive.

- Particles that transmit radiation are not radioactive.
- Irradiated water creates transient radicals
 - Hydroxyl radical (•OH-)
 - Hydrogen atom (•H+)
 - Solvated electrons (e⁻_{aq})
- Free radicals damage DNA and intercellular structures within living cells.



http://www.npr.org/blogs/thesalt/2012/01/12/145107755/why-x-rayed-food-isnt-radioactive-and-other-puzzles

Bacteriophage & E. coli Inactivation in Tap Water



Gerhinger et al., 2003. Bacteriophages as viral indicators for radiation processing of water: A chemical approach.

Efficacy of E-Beam on Seeded Microorganisms 0.0 1.0 Log 10 Inactivation 2.0 3.0 4.0 5.0 6.0 7.0 0 5 10 15 20 E-Beam Dose (KGrays)


E-beam Workshop at FermiLab, May 2018

♦ PRD-1

MS2


Fecal Coliforms

Efficacy of E-Beam on HPC



E-beam Workshop at FermiLab, May 2018


Electron Beam Inactivation of Cryptosporidium (Potable Water)



Efficacy of E-beam on Selected DBPs for each Dose on Unchlorinated Reclaimed Water (Site 1)

Compound Ebeam Dose (Kgray)	Percent Removal					
	1	5	10	15	20	
Dichloroacetic acid	0.00	52.94	77.94	80.44	85.29	
Total Haloacetic acids	4.04	62.32	84.85	86.57	89.90	
Trichloroacetic acid	12.90	82.90	>93.87	>93.87	>93.87	
Bromodichloromethane	16.67	>94.44	>94.44	>94.44	>94.44	
Chloroform	45.15	87.97	>99.05	>99.05	>99.05	
Total Trihalomethanes	52.38	89.56	>99.27	>99.27	>99.27	
Removal Range	0 - 52%	>53%	>78%	>80%	>85%	

Effects of E-beam Treatment on Select Organic Compounds




Efficacy of E-Beam on DOC

0.00

Inf

Start-Loc 1a 0

1



Ebeam Dose (K Gy)

10

15

20

Inf.


Finish

Loc 1a

E-beam Workshop at FermiLab, May 2018


5

Efficacy of E-Beam on Color of Unchlorinated Reclaimed Water (250nm UV)



Dose Ranges & Cost for Various Applications

Ionizing effects are stated in terms of the absorbed dose



E-Beam for Water Treatment Timeline

Food & Agriculture Research

F. Minsch used "X-"

E-Beam
Research
Center
Established
(Miami-Dade
WWTP)

1988

Waterborne pathogen inactivation studies

• 1998-2007

Miami-Dade Research Facility & Mobile Unit Dismantled: Worldwide interest grows for industry & textile, flue gasses, & food processing uses.

• 2012+

• 1896


radiation"

to kill food microbes

E-Beam Applications for Water Treatment:

- Process is technically sound and founded on good science.
- Demonstrated capable of non-selective destruction of organic compounds:
 - Endocrine disruptors
 - Pharmaceuticals
 - Toxic Organic Chemicals
 - Pesticides
 - Disinfection By-Products (DBPs)
 - THM
 - Nitrosamines
 - Brominated compounds
- Biosolids Treatment De-watering and Composting
 - Original Application of Miami and Deer Island (Boston)
- Disinfection achieved in complex matrices (highly turbid water, sludge, and RO membrane concentrate, textile dyes, etc., etc., etc...).





treatment technology??

E-Beam Process


- High density electron stream injection throughout water volume resulting in formation of:
 - Electrically excited states
 - Free radicals
- Rapid Reaction Rate
 - 10⁻⁷ seconds after irradiation yields

$$H_2O \xrightarrow{e^-} [2.6]e_{aq}^- + [0.6]H \cdot + [2.7] \cdot OH +$$

$$[0.7]H_2O_2 + [2.6]H_3O^+ + [0.45]H_2$$

- Unique no other AOP can generate oxidizing and reducing chemistry simultaneously
- Importance of the three free radicals (•OH, H•, and e-aq)

THE ELECTROMAGNETIC SPECTRUM



Gigahertz (GHz) 10-9 Terahertz (THz) 10-12 Petahertz (PHz) 10-15 Exahertz (EHz) 10-18 Zettahertz (ZHz) 10-21 Yottahertz (YHz) 10-24

The Real Difference Is The Result

- Facilitate contaminant destruction by allowing for multiple reaction pathways
 - Greater potential to mineralize
 - Less potential for reformation
- Residual disinfectant (H_2O_2)
- Energy Efficiency
- High Energy Delivery = Excellent Disinfection Capacity
 - Lethal doses
 - Instantaneous/short duration
 - USEPA approved for sludge disinfection
- Non-selective destruction of organics
- Rapid chemical reactions
 - Supports flow through applications
 - Excellent process flexibility

Why?

- pH Independent
 - $_{\circ}~$ Equal performance from pH 3 to 11
- Solids Independent
 - 。 Sediments, soils, sludges
- Non Contact Apparatus
 - No fouling of lamps or membranes

Why?...continued

- Temperature Independent
 - Variations have no treatment impact
- No organic sludge
 - Organics are mineralized
 - Reduces sludge generation from secondary treatment processes (like filtration)
- No air emissions
 - Aqueous technology
 - No NO_X and SO_X

Why...continued

- Flexibility for use at either end of pipe
 - Pretreatment/post treatment
 - Organics, Microbiological
 - Extend membrane life (prevents fouling)
 - Synergy with other processes
 - Sterilize ahead of RO/filtration
 - Improve performance of Biological treatment processes
 - Treats recalcitrant compounds

El cost n Beam Economics

- Electron beam accelerators are available from 0.5 - 10 MeV in power levels from 5 - 1000 kW
- Capital cost (\$10,000 \$35,000/kW)
 - Function of system size power requirements
 - Dose requirement
 - Linear dependence on process rate
 - Logarithmic dependence on contaminant concentration
 - Offset by low operating cost
 - \$0.04/ton per kGy
 - \$0.15/1000 gal per kGy
 - assumes electricity cost at \$0.10 kWh and 70% E-beam utilization efficiency

Nitrite Oxidation

Nitrite ion readily/rapidly oxidized to nitrate ion via two pathways

$$\bullet OH + NO_2 \rightarrow \bullet NO_2 + OH$$

$$\bullet OH + CO_3^{2-} \rightarrow CO_3^{\bullet} + OH^-$$

•OH + •NO₂
$$\rightarrow$$
 H⁺ + NO₃

$$CO_3 \bullet^- + \bullet NO_2 \rightarrow NO_3 + CO_2$$

NDMA Destruction

- NDMA formed from*:
 - Oxidation of UDMH (CH₃)₂NNH₂
 - Reaction of DMA + HNO₂/NO_x/NH₂Cl
- NDMA reversibly oxidized to dimethylnitramine

$$R_2NO$$
 $\xrightarrow{Ox/hv}$ R_2NO_2

^{*}Tuazon et al., Env. Sci. Techt 15, 283, (1981)