



Radiation Effects on Plastic Scintillators for Current and Future HEP Experiments


A. Belloni

University of Maryland

Research Techniques Seminar Fermi National Accelerator Laboratory November 20th, 2018



Plastic Scintillators in HEP




- Material of choice for hadron calorimeters of currently operating detectors
 - Commercially available in the large quantities needed for big detectors; plastic scintillators are cheap
 - They can be molded in any shape, provide design flexibility
 - They are fast: can provide info about energy in event in time for online selection
- Plastic degrades during irradiations
 - LHC detectors operate in unprecedented hostile conditions






History of Scintillation Detectors



- 1903: Crookes builds first scintillation detector
 - A film of ZnS, scintillating when hit by an α particle; light detected by human operator (using microscope...)
- 1944: Curran and Baker introduce the PMT
 - Convenient replacement for naked eye; revives interest in scintillation detectors
- 1964: Birks "The Theory and Practice of Scintillation Counting"
- ~1990: SSC experiments raise the threshold for radiation tolerance
 - Many lessons taken (and some forgotten...) in design of LHC experiments




Ubi Crookes ibi lux



CMS HCAL Ageing




- The CMS Hadron calorimeter uses plastic scintillator as active material
 - It is know that radiation breaks the plastic and creates "color centers" which absorb scintillation light
- The crucial question: how long will it take the HCAL to become dark?
 - The lesson from 2012 data: shorter than it was originally thought
- R&D efforts aims at identifying a more radiation-tolerant material usable in HCAL upgrade and future detectors
 - Time scale: Long-Shutdown 3 upgrades (2024-2026)




After an irradiation of 10krad, we see the light-yield reduction predicted for 1Mrad



Outline








How does a Scintillator work?




- An organic scintillator is typically composed of three parts
 - A polymer base
 - Typically PVT, polystyrene, or silicon-based materials
 - A primary dopant (~1%)
 - A secondary dopant (~0.05%)
- Particles excite the base, the excitation of the base can migrate to the primary dopant, producing detectable light
 - In crystals, excitons transfer the energy; in liquids, solvent-solvent interactions and collisions
- The secondary dopant shifts the light to longer wavelengths, to make it more easily detected
 - Maximize the overlap with the wavelength range at which photodetectors are most efficient







Chemistry Refresher



- Most common scintillator bases are PVT and PS, all carbon-based
 - The parts of interest are the C₆H₆ aromatic cycles
- Carbon atom has four external electrons, all participating in bond
 - One of 2s² electrons promoted to 2p level
- The trigonal hybridization of sp³ orbitals is luminescent
 - One p orbital untouched (π electrons), the other sp² orbitals mix into shared orbitals, at 120 degrees (σ electrons)
- At leading order, the light yield of the base is proportional to the ratio of π to σ electrons
 - More complex monomers enter the picture at NLO
 - Maximal LY reached by anthracene C₁₄H₁₀





Sigma Bonds sp² Hybridized orbitals







Commonly Used Polymers







methylmethacrylate



PMMA

e.g.: WLS fibers

PMMA added for completeness: not used in scintillators!




Polymer Substrate Excitation



- Four excitation mechanisms:
 - 1. Excitation into π -electron singlet state
 - 2. Ionization of π -electron
 - 3. Excitation of electrons other than π -electron
 - 4. Ionization of electrons other than π -electron

... with different outcomes:

- 1. Fast scintillation
- 2. Ion recombination leads to excited triplet or singlet π electron states: slow scintillation
- 3. Thermal dissipation
- 4. Temporary (Birks' law) and permanent molecular damage
- Typically, 2/3 of energy yields molecular excitation,
 1/3 goes to ionization
 - Scintillation probability for benzene ~ 10%
 - Multiply 2/3 by fraction of π -electrons






Light Production – Stokes' Shift



- Both ground and excited states have many vibrational sub-levels
 - Crucial feature is that inter-atomic spacing is larger in excited states than in ground states, hence de-excitation goes to sublevels above ground S₀₀
 - Non-radiative transition to S₀₀ follows
- De-excitation path leads to separation between absorption and emission spectra: <u>Stokes' shift</u>
 - Depends on environment around atom; how molecules are folded; proximity to other molecules; proximity of radicals






Light Production – Stokes' Shift




- Both ground and excited states have many vibrational sub-levels
 - Crucial feature is that inter-atomic spacing is larger in excited states than in ground states, hence de-excitation goes to sublevels above ground S_{00}
 - Non-radiative transition to S₀₀ follows
- De-excitation path leads to separation between absorption and emission spectra: <u>Stokes' shift</u>
 - Depends on environment around atom; how molecules are folded; proximity to other molecules; proximity of radicals







The Role of Dopants




- Energy transfer from base to primary dopant
 - Initial excitation transferred to dopants radiatively (in deep UV) or via dipole-dipole interactions (Forster mechanism)
 - Non-radiative fraction increases with dopant concentration
 - Common primary dopants: PTP (p-Terphenyl), PPO
- ... and from primary to secondary dopant
 - Radiative transfer
 - Common secondary dopants: POPOP, TPB, K27, 3HF
- Executive summary
 - Dopants shift wavelength of emission further away from base-material absorption range
 - Note: Stokes' shifts change when dopants mixed in with base







Radiation Damage




- Dominant mechanism is damage to base material
 - Dopants are mostly radiation-hard
- Two components to light-yield reduction of plastic scintillator
 - Reduction of initial light yield
 - Absorption of light produced by secondary dopant
 - "Color centers" reduce the attenuation length

Effects of radiation:

- Breaks polymer chains and create radicals that absorb UV light
 - Irradiated scintillator turns dark


Some parameters to model radiation damage

- Presence of oxygen
- Total irradiation dose and dose rate
- Temperature of irradiation






Investigating Radiation Tolerance




- Identify candidate materials offering improved radiation tolerance
 - Tune dopant concentration
 - Emit at a longer wavelength
- Irradiate materials in different environmental conditions, at different total doses and dose rates
 - Radioactive sources (Co-60, Cs-137)
 - LHC beam halo: CASTOR Radiation Facility
- Measure light yield with different and complementary methods
 - Spectrofluorometers, cosmic rays, radioactive sources
- Map light-yield reduction as a function of multiple parameters
 - O₂ concentration; total dose; dose rate; temperature; dopant concentration...





Irradiation Facilities (1)





University of Maryland

Co-60 source

50-1500krad/hr


(picture: TRIGA reactor...)

NIST

- Co-60 source
- 50-500krad/hr
- Cold (-30C) and warm irradiations


Goddard Space Flight Center


- Co-60 source
- 0.3-100krad/hr
- Cold (-30C) and warm irradiations





Irradiation Facilities (2)





CERN CASTOR Calorimeter Table

- LHC environment
- O(10) of CMS highest dose rate

CERN GIF++


- Cs-137 source
- 0.05krad/hr



Spectrofluorometry (1)



- Very challenging measurement
 - Typical user needs accurate measurement of peak positions, not peak amplitude
- Tuned procedure until reached satisfactory level of repeatability
 - Repeated measurements during a day vary within <2%
 - Include uncertainty on machine conditions, placement of sample by operator, inhomogeneity among sample sides
- Possible to probe effect of radiation on dopants separately by varying excitation wavelength
 - E.g. blue scintillator: 285nm (excite primary), 350nm (cross primary/secondary), 400nm (excite exclusively secondary)






Spectrofluorometry (2)



Horiba Fluoromax4+







UMD-designed sample holder



Spectrofluorometry (3)









- Technique allows one to understand effect of radiation on dopants
 - One can excite dopants separately, and check efficiency of energy transfer between them



Transmission/Absorption




- CARY 300 UV-Visible spectrophotometer
 - Double-beam mode to reduce uncertainties
- Measurement (somewhat) sensitive to bulk effects
 - Samples are 1-cm thick, completely traversed by incident light
 - Measure annealing times of order ~ few weeks
- Absorption spectra used as input to GEANT simulations
 - Important step in understanding plastic damage is availability of tuned simulation of optical properties of plastic






Transmittance Measurements



- Measurement details
 - Commercial EJ-200
 - 5.82Mrad at 80krad/hr, NIST
 - Irradiation at 23C vs. -30C
 - Samples annealed about 20 weeks at room temperature
- Observations
 - Peak at ~400nm (absorption maximum of secondary dopant) seems to indicate some damage of secondary dopants
 - Less dopant to absorb light → higher transmittance
 - Comparable transmittance above 410nm after annealing






Alpha Source Measurements



- Sensitive to complete chain of light production
 - Source releases energy in the base, and the whole chain of dopants and energy transfers is exercised
 - Spectrophotometer cannot produce UV light to mimic base-toprimary transfer
 - Somewhat sensitive to bulk damage
 - Energy released at small depth; light transverses about 1cm of scintillator to reach PMT
- Provides complementary measurement to transmission and emission spectra
 - Closer to actual operation of scintillator in detector





Dose-rate Effect (1)




- A counter-intuitive re-discovery
 - When the same dose is integrated over a longer period, the damage is larger
- First reports of dose-rate dependency in '90
 - Working hypothesis: oxygen diffusion into plastic permits more reactions that create UV-absorbing radicals
- Light yield decreases exponentially as a function of integrated dose *d*:

$$L(d) \propto e^{-\frac{d}{D}}$$

 The dose constant D increases as the dose rate does

Hatched area: systematic uncertainty







Dose-rate Effect (2)



 $L(d) = L(0) \cdot \exp(-d/D)$; d: dose, D: dose constant




- Radiation damage (per unit of integrated dose) increases at low dose rates
 - Power law between dose constant and dose rate matches what we would expect under the assumption that oxygen diffusion drives the dose-rate effect
 - Is oxygen diffusion driving the dose-rate dependency?






More to Dose-rate Effect



- Oxygen diffuses up to a depth z_0 into the substrate
 - Diffusion depth proportional to $1/\sqrt{R}$, where R is the dose rate
 - Proportionality coefficient depends on diffusion constant, solubility constant, oxygen pressure, and rate of formation of radicals



- Defined as the product of the density of color centers and their cross section for light absorption
- The color-center density and type depend on the presence of oxygen
- The light yield can be written using a dose-rate-dependent effective absorption coefficient
 - Dose constant $D = \frac{\sqrt{R}}{a + b\sqrt{R}}$
 - Observe \sqrt{R} dependence of dose constant for small dose rates; expect D to tend to a constant value for high dose rates (oxygen has no time to diffuse at all)



$$L \propto e^{-\mu_1 \cdot 2z_o - \mu_2 \cdot t}$$

t: sample thickness

 z_0 : oxygen diffusion depth

 μ_1 : absorption coefficient in the

presence of oxygen


 μ_2 : absorption coefficient independent of oxygen




Variant Thickness Studies




- Attempt at disentangling effect of oxygen diffusion on absorption coefficient
 - Measure effective absorption coefficient in lab using transmission/absorption and α -source measurements
- Laboratory measurements of samples with different thickness used as inputs to GEANT4 simulation
 - Final goal is measurement of wavelengthdependent absorption coefficients in oxygen-depleted vs oxygen-filled regions, and of diffusion depth z_0 vs radiation dose rate








Very-Low Dose-Rate Studies




- Lowest dose-rate measurement performed in-situ with HE laser and radioactive-source calibration system
 - First results presented after integration of 0.2Mrad in about two years of LHC operations (2010-2012)
 - Continued to update results as more data were collected
 - Radiation effects on scintillator, wavelengthshifting fibers, and photosensors are combined
- GIF++ facility allows for probing similar dose rate as in the case of the HE detector
 - Cs-137 source, dose rate ~ 50rad/hr
 - Irradiated samples measured in laboratory, and radiation damage on plastic measured independently of other contributions



2-year long irradiation at GIF++ ~300kRad @ 50rad/hr α-source measurement



Base-Material Studies



- Investigation of scintillator produced with same dopant configuration, and different base
 - Green and blue fluors
 - Normal concentration of fluors; over-doped primary (2x);
 over-doped secondary (2x)
 - Polyvinyltoluene and polystyrene base
- CMS Hadron Calorimeter uses PS-based scintillator; current commercial scintillators mostly PVT-based
 - One note of interest: oxygen diffusion coefficient (measured in cm²/s) is 13 times larger in PVT than in PS
- Measurements on irradiated samples suggest that PVT-based scintillators are more radiation-tolerant than PS-based scintillators






Co-60 Irradiation at NIST 7Mrad @ 500krad/hr



Over-doping Studies







- Polystyrene vs polyvinyltoluene blue scintillators; Co-60 irradiation, 7Mrad @ 500krad/hr
 - 1X1P: commercial version; 1X2P and 2X1P: over-doped versions
 - The concentration of the primary or secondary dopant is doubled
- Pictures suggest that over-doping helps preserve the scintillator clear, and confirm that PVT seems to hold better than PS
 - Measurement of dose constant reveals that over-doping marginally improves radiation tolerance
 - Important note: the 1X1P and 1X2P samples annealed for about 12 hours longer than the 2X1P



Dose-Constant Summary



- Basic model captures behavior of plastic scintillator under irradiation in large range of dose rates
 - Ideally, would need more low-dose rates to check behavior
- Quick take-home message from plot
 - PVT performs better than PS
 - Over-doping improves radiation tolerance marginally
- More measurements available
 - Some left out to avoid cluttering the plot,
 some need to be cross checked






CMS HCAL σ-Tiles




- Studies on scintillator properties performed using 1x1x5cm³ rods
 - Mechanical constraints imposed by spectrophotometers
- Tiles in CMS HCAL are thin squares, with a wavelength-shifting fiber inserted in a groove close to the edge
 - Typical size: 10x10x0.4cm³
 - The σ-tile design demonstrated to maximize uniformity of light collection vs. particle crossing position
- The light collected by the WLS fiber is then transported to photosensors via a clear fiber
 - Setup allows photosensors to be installed in an area with lower radiation





Irradiations @ LHC







- Comprehensive set of samples installed next to LHC beam
 - From scintillator in current HE to patent-pending materials
- Each tile is connected to the CMS DAQ and HCAL Calibration systems
 - A laser fiber can excite directly each tile, and provide a signal with known amplitude
- The system allows for the continuous monitoring of scintillator ageing
 - Irradiation conditions more closely match the conditions of actual detectors



Castor Radiation Facility




- Two rounds of irradiations, in different position w.r.t. LHC beamline
 - Investigated different range of dose rate
- Very challenging effort compared to laboratory measurements
 - Light collected via wavelength-shifting fiber connected to clear fiber
 - Photosensors also installed in radiation area
- Ongoing analysis of live data collected during LHC operations
 - One-time measurement of scintillator performance in laboratory (after annealing) useful to normalize results



CRF Scintillator boxes



Tile Testing at CERN H2




- Test beam facility at CERN
 - Focused on 150GeV muon sample (MIP)
 - Tracking information provided by set of wire chambers
- Sample tiles connected to full CMS HCAL DAQ chain
 - Test of both the scintillator and the data-acquisition system
- Measured light-collection efficiency and yield
 - A collection of unirradiated scintillator samples



CMS HCAL Wedge

JINST 13 P01002



EJ-200: hit efficiency map


On-going measurement of uniformity of light collection efficiency and light yield on *irradiated* tiles



The CMS HGCAL





- LHC experiments will undergo an important upgrade in 2024-2026 (Phase-II Upgrades)
 - Necessary to overcome HL-LHC challenges: high interaction rate; significant radiation dose to be integrated over 10 years of operations
- CMS Phase-II Endcap calorimeter embraces the Particle-Flow approach to calorimetry
 - Design high-granularity detector to identify contribution from charged and neutral particles
- Key parameters of CMS HGCAL
 - $-1.5 < |\eta| < 3.0$
 - 600m² Si sensors; 500m² scintillator; 6M channels
- CE-E
 - Cu/CuW/Pb absorber; silicon sensors
 - $-28 \text{ layers}; 25X_0, \sim 1.3\lambda$
- CE-H
 - Steel absorber silicon and scintillator
 - − 24 layers; ~8.5λ






HGCAL Mechanical Layout





Mixed Si-scintillator layer Boundary optimized vs radiation hardness Scintillator too in cold volume (-30C)




CALICE AHCAL




SiPM-on-Tile Setup



- Photosensor (SiPM) mounted directly on tile
 - Direct collection of scintillator light
 - Tile wrapped with reflective cover
 - Central dimple in tile optimizes light collection
- Cosmic-ray runs with prototype assembly
 - CALICE AHCAL prototype (similar structure to CE-H) tested at CERN Test Beam facility
- Scintillator tile and photosensor kept within the cold volume (-30C) in HGCAL design
 - Critical R&D question: how do scintillators behave when cold?








Cold Scintillators



BC404 Overlay [All temperatures]







- Pulse shape and timing unaffected by temperature
 - Tested down to -180C (scintillator in liquid nitrogen)



Cold Irradiation Annealing




- Monitoring annealing of damaged scintillator
 - 1x1x5cm³ samples of plastic scintillator
 - Light yield with α -source
- Low temperature slows annealing, but no difference in permanent damage
 - Consistent with na
 ïve expectation that
 creation of radicals and their reaction
 with diffused oxygen decrease with
 temperature






Cold vs. Warm Irradiation







- Measured annealing (at room temperature) of samples irradiated at 23C and -30C
 - Indication that temporary damage anneals completely after ~4 months
 - Permanent damage is smaller in cold-irradiated samples




Photosensors Matter



Design of radiation-tolerant detector must include all components

- Lesson from CMS HE: observed light-yield reduction partially due to damage on photosensors (hybrid photo-diodes – HPD)
 - And another part to damage to wavelengthshifting fibers
- R&D effort devoted to characterizing radiation tolerance of photosensors
 - Important contribution to detector design

Jim Hirschauer



SiPM noise in 50ns gate (~CMS Hadron Barrel light pulse)



A Look After HL-LHC




• Long-term prospective: 2030-2080

- FCC-hh: 100km, 100TeV

- ILC: 50km, e^+e^- at 1TeV


- CEPC/SppC: 50km/100km, 100TeV

- Design of future detectors already started
 - R&D on granularity limits of noble liquid calorimeter
 - Dual-readout calorimetry





Summary and Prospects



- Dose-rate effect and oxygen
 - Observe dependence based on dose rate, and diffusion depth
- Systematic study of radiation damage as a function of the scintillator composition
 - (Marginal) indications that emitting at longer wavelengths and increasing dopant concentration improve radiation tolerance
- Irradiations in cold environment (-30C)
 - Measurements do not seem to indicate cold is bad; on-going investigating at lower dose rates, to understand temperature dependence of oxygen diffusion, quenching of radicals, damage on dopants
- Modeling of radiation damage has multiple facets, with important correlations
 - Extent of damage, and type of damage, depends on integrate dose, dose rate, atmosphere (oxygen content and pressure), temperature, scintillator composition...
 - Literally years of measurements, converging toward set of publications
- Plastic scintillators are cheap, safe, and fit any detector design
 - Increasing their radiation tolerance can provide a good candidate material for large detectors where the
 expected integrated dose over the experiment lifetime is of the order of a few Mrad






Additional Material



Bibliography




- The Theory and Practice of Scintillation Counting; J.B. Birks
- Design of Fluorescent Compounds for Scintillation Detection; A. Pla-Dalmau, DOI: 10.2172/1426712
- Brightness and uniformity measurements of plastic scintillator tiles at the CERN H2 test beam; CMS HCAL Collaboration, <u>JINST 13 P01002</u>
- Dose rate effects in the radiation damage of the plastic scintillators of the CMS hadron endcap calorimeter; CMS HCAL Collaboration, <u>JINST 11 T10004</u>
- Results of a low dose rate irradiation of selected plastic scintillating fibers; C. Zorn, B. Kross, S. Majewski, R. Wojcik, K.F. Johnson, <u>DOI: 10.1109/NSSMIC.1991.259159</u>
- Dose-rate dependence of the radiation-induced discoloration of polystyrene; K.T. Gillen, J.S. Wallace, R.L. Clough, <u>Rad. Phys. Chem. 41 No 1/2, 1993</u>
- Spatially resolved UV-VIS characterization of radiation-induced color centers in poly(styrene) and poly(vinyltoluene); P.C.Trimmera, J.B.Schlenoffa, K.F. Johnson, Rad. Phys. Chem. 41 No 1/2, 1993
- Radiation induced oxidative degradation of polymers—I: Oxidation region in polymer films irradiated in oxygen under pressure; T. Seguchi, S. Hashimoto, K. Arakawa, N. Hayakawa, W. Kawakami, I. Kuriyama, Rad. Phys. Chem. 17 No 4, 1981



(Surface) Annealing




- Monitor evolution of ratio between integrals of emission spectra (irradiated vs. reference) to estimate annealing time
 - Emission measurement sensitive to (mostly) annealing of surface
 - Faster annealing time w.r.t. transmission measurements
 - Consistent with being sensitive exclusively to surface effect





Polymers





styrene

polystyrene