ProtoDUNE-SP Beamline Calibration

M. Tzanov *Louisiana State University*

ProtoDUNE DRA meeting, Apr 17th, 2019

ProtoDUNE-SP Beamline Calibration

Motivation

- Improve the momentum and TOF calibration fine tune
- Obtain the momentum scale and systematic uncertainty
- Needed by cross section analyses and perhaps for TPC calibration
- Examine beamline performance
 - found some puzzling bands in phase space

ProtoDUNE-SP Beamline Calibration Procedure

 Exploit the proton and kaon mass scales to simultaneously obtain calibration for TOF and p.

 $m = \frac{p}{c}\sqrt{\frac{t^2}{t_l^2}} - 1$, where t is the TOF, t_l is the time light travels between the TOF beam monitors (d = 28.575 m) and p is the momentum.


- Assume additive correction for TOF-> $t \Delta t$, and multiplicative for the momentum p-> αp . Good model for small corrections.
- For two protons with reconstructed TOF and momenta $(t_1, p_1), (t_2, p_2)$ $\frac{m^2}{m^2} = \frac{\alpha^2 p_1^2}{\alpha^2 p_2^2} \frac{((t_1 - \Delta t)^2 - t_l^2)}{((t_2 - \Delta t)^2 - t_l^2)} = 1, \text{ where } \alpha \text{ cancels allowing to determine } \Delta t.$ • Similarly, for proton and kaon with the same momentum p with t_p, t_K $\frac{m_p^2}{m_K^2} = \frac{\alpha^2 p_p^2}{\alpha^2 p_K^2} \frac{((t_p - \Delta t)^2 - t_l^2)}{((t_K - \Delta t)^2 - t_l^2)}, \text{ and } \alpha \text{ cancels again.}$


ProtoDUNE-SP Beamline Calibration Procedure

• Exploit the proton and kaon mass scales to simultaneously obtain calibration for TOF and p.


 $m = \frac{p}{c} \sqrt{\frac{t^2}{t_l^2}} - 1$, where t is the TOF, t_l is the time light travels between the TOF beam monitors (d = 28.575 m) and p is the momentum.

- Assume additive correction for TOF-> $t \Delta t$, and multiplicative for the momentum p-> αp . Good model for small corrections.
- In this analysis perform a binned 2-parameter fit (α, Δt) where the proton sample is binned in momentum and TOF is obtained for each momentum bin.
- Using 1,2,3,6 GeV runs EventTree provided by the BI group
- Only GOLDEN events with eventRank = 1.






TOF vs Momentum, All TOF Channels, Golden





- All TOF Channels
- Extra proton band
- Multiple bands with TOF offset


TOF vs Momentum, All TOF Channels, Golden





- All TOF Channels
- Extra proton band
- Multiple bands with TOF offset
- Stripes for fine binning.













• 1 GeV run proton kinematic region.




- AA TOF Channels
- Cleanest
- Extra proton band is there.
- Zoom in for 1GeV.
- Red multiple
 reconstructed TOF
- Blue single
 reconstructed TOF

• 1 GeV run proton kinematic region.



• 1 GeV run proton kinematic region.



• Different TOF channels sample different deflection angles. Results in different momentum distributions.

A and B channels are physically next to each other.

ProtoDUNE-SP Beamline Calibration Procedure


• Exploit the proton and kaon mass scales to simultaneously obtain calibration for TOF and p.

 $m = \frac{p}{c} \sqrt{\frac{t^2}{t_l^2}} - 1$, where t is the TOF, t_l is the time light travels between the TOF beam monitors (d = 28.575 m) and p is the momentum.

- Assume additive correction for TOF-> $t \Delta t$, and multiplicative for the momentum p-> αp . Good model for small corrections.
- In this analysis perform a binned 2-parameter fit (α, Δt) where the proton sample is binned in momentum and TOF is obtained for each momentum bin.
- Using 1,2,3,6 GeV runs EventTree provided by the BI group
- Only GOLDEN events with eventRank = 1.
- Use only AA channel for this study. Check results for all.


 Select protons and kaons based on mass and Cherenkov – remove the extra band for 1GeV and 2GeV runs

TOF vs Momentum, 1GeV Run, AA, Protons, Golden




 Select protons and kaons based on mass and Cherenkov – remove the extra band for 1GeV and 2GeV runs

TOF vs Momentum, 2GeV Run, AA, Protons, Golden



TOF Fits


• Truncated fits to the mass TOF peaks.




50MeV mom
Bins for 1GeV and
2GeV runs.

100MeV mom
 Bins for 3GeV and
 6GeV runs.


Before Mass Fit




Before Mass Fit




After Mass Fit




Mass Distribution for Fit Points



Squared Mass Distribution for Whole AA Sample



Squared Mass Distribution for All TOF



26


Conclusions

- ProtoDUNE-SP beamline calibration was examined
- BI group has done an excellent job
- Obtained data driven fine tune of the momentum scale with less than 0.5% uncertainty.
- This fine calibration can be applied to all TOFChannels
- Analyzers should be careful with selection to avoid biases.

BACKUP Slides


• Select protons and kaons based on mass

TOF vs Momentum, 3GeV Run, AA, Protons, Golden




Select protons and kaons based on mass

TOF vs Momentum, 6GeV Run, AA, Protons, Golden




Select protons and kaons based on mass

TOF vs Momentum, 3GeV Run, AA, Kaons, Golden




Select protons and kaons based on mass

TOF vs Momentum, 6GeV Run, AA, Kaons, Golden



TOF Fits

• Truncated fits to the mass TOF peaks.




50MeV mom
Bins for 1GeV and
2GeV runs.


100MeV mom
 Bins for 3GeV and
 6GeV runs.


TOF Fits


• Truncated fits to the mass TOF peaks.



Squared Mass Distribution for Fit Points










After Fit Before Proton Mass

Squared Mass Distribution for Fit Points







After Fit Before Proton Mass