ProtoDUNEBeamCuts

Jake Calcutt Oct. 16, 2019





Introduction

Implemented new class to handle selecting good beam events


protoana::ProtoDUNEBeamCuts

Refinement/expansion on the method within ProtoDUNETrackUtils class


Takes in a FHiCL parameter set to create cuts for each momentum for both data & MC.

- Automatically chooses between data/MC
- MC: Compares to beam MCParticle projected to TPC face (z=0)
- Data: Compares to ProtoDUNEBeamEvent Track at TPC face

Cut Technique



Parameter Set Structure



FHiCL File Structure

```
76 MCCuts List: [
 Within ProtoDUNEBeamCuts.fcl
                                                         @local::SPProd2 MC sce p3GeV.
                                                    78
                                                    79
                                                         @local::SPProd2 MC sce p5GeV.
 102 Prod2BeamCuts:
                                                    80
103
      MCCuts:
                @local::MCCuts List
                                                         @local::SPProd2 MC sce 1GeV,
                                                    81
      DataCuts: @local::DataCuts List
 104
                                                    82
                                                         @local::SPProd2 MC sce 2GeV,
105
                                                    83
                                                         @local::SPProd2 MC sce 3GeV,
                                                    84
                                                    85
                                                         @local::SPProd2 MC sce 6GeV.
                                                    86
                                                         @local::SPProd2 MC sce 7GeV
                                                    87 ]
                                                    88
                                                       DataCuts List: [
 Within module FHiCL file
                                                    90
                                                         @local::SPProd2 Data sce p3GeV,
                                                    91
                                                    92
                                                         @local::SPProd2 Data sce p5GeV.
14 #include "ProtoDUNEBeamCuts.fcl"
                                                    93
15 #
                                                    94
                                                         @local::SPProd2 Data sce 1GeV.
                                                         @local::SPProd2 Data sce 2GeV,
                                                    95
                                                         @local::SPProd2 Data sce 3GeV,
                                                    96
     BeamCuts: @local::Prod2BeamCuts
                                                    97
40
                                                    98
                                                         @local::SPProd2 Data sce 6GeV,
                                                         @local::SPProd2 Data sce 7GeV
                                                    99
                                                   100 ]
```

```
1 #include "dune/Protodune/Analysis/ProtoDUNEBeamCuts.h
 3 namespace example {
                                                                                         Include beam cuts class
    class ExampleAnalyzer;
 7 class example::ExampleAnalyzer : public art::EDAnalyzer {
 8 public:
    //Constructors and other public members here
                                                                                          Declare the parameter
10 private:
                                                                                          set and beam cuts class
    1/Other Members Here
    fhicl::ParameterSet BeamCuts:
    protoana::ProtoDUNEBeamCuts beam cuts;
14
16 example::ExampleAnalyzer::ExampleAnalyzer(fhicl::ParameterSet const & p)
                                                                                            Import beam cut
     : EDAnalyzer{p}
    /*Initialize Other Members Here,*/
                                                                                            parameters and
    BeamCuts(p.get<fhicl::ParameterSet>("BeamCuts"))
20
                                                                                            initialize the class
    beam cuts = protoana::ProtoDUNEBeamCuts( BeamCuts );
22
  void example::ExampleAnalyzer::analyze(art::Event const& evt)
25
26
    //Get the track pointer: *thisTrack
    bool pass beam cuts = beam cuts.IsBeamLike( *thisTrack, evt, "1");
                                                                                            Check the track
```

Miscellanea

Can only use these settings

Will throw exception otherwise. Up to users to decide what to do (i.e. let crash or catch it and carry on)

Tip: use fcl parameter to easily switch between different momentum settings

Miscellanea

```
126 BeamVals result;
127 result.Valid = false;
128
129 if( !true_beam_particle ){
130    std::cout << "No true beam particle" << std::endl;
131    return result;
132 }
133
```

Current implementation:

Cut method returns 'false' if no MC particle describing beam **or** the beam event from data has != 1 track associated

Is there a better way to handle this?

Thanks for listening



