



**Lawrence Livermore
National Laboratory**

C. Roca, on behalf of the ROADSTR Near-Field Working Group:

T. Akindele, N. Bowden, L. Carman, T. Classen, S. Dazeley, M. Ford, V. Li, M. Mendenhall, F. Sutanto, N. Zaitseva and X. Zhang, S. Durham

presents:

DESIGN, TEST AND PRODUCTION AT LLNL OF:

NOVEL PSD PLASTIC SCINTILLATOR TECHNOLOGIES FOR NEUTRINO DETECTION

Snowmass Summer Meeting 2022 - 25.VII.2022

STATE OF THE ART: ABOVEGROUND REACTOR NEUTRINO DETECTION




PROSPECT has demonstrated first high sensitivity aboveground detection and identified important capabilities.



Segmentation


Li doped scintillator

PSD capabilities



There is a strong interest in readily mobile precision neutrino flux detectors

MOTIVATIONS FOR READILY MOBILE ABOVEGROUND DETECTION SYSTEM



Nuclear safeguards and verification applications




- ▶ Potentially useful tool for negotiation and verification of nuclear agreements.
- ▶ Advanced reactors may be difficult to safeguard with conventional approaches.

PROSPECT aboveground demonstration has inspired new use cases studies.

Readily mobile systems have several motivations

Multi-reactor measurement campaign with same mobile detector design



- ▶ Benchmarks for applications
- ▶ Validating flux & spectrum predictions against diverse fuel types.

There is a strong interest in readily mobile precision neutrino flux detectors

PSD PLASTIC MATERIALS: HOMOGENOUS ^6Li -DOPING


- ▶ Building on more than a decade of effort at LLNL by **N. Zaitseva, A. Mabe & M. Ford**
- ▶ Eljen Technology has started mass-producing PSD plastic bars with lab's formulation.

Developing formulations and production processes




Exploring solubility of multiple Li bearing compounds and their stability

Transferring technology for commercial production



Evaluating light yield, attenuation length, PSD properties





Build up a characterization setup to test bars as they are produced

BASICS OF PSD PLASTIC CHEMISTRY



Traditional PSD Plastic

Monomer for matrix





Primary and secondary dyes are responsible for PSD and wavelength shifting

BASICS OF PSD PLASTIC CHEMISTRY




Lithium salts are added to ensure correlated event selection through n-capture process

BASICS OF PSD PLASTIC CHEMISTRY





Addition, mixing and curing of components require very strict condition controls

SOLUBILITY OF ${}^6\text{Li}$ SALTS



23 °C; 85:15 styrene:MAA




65 °C; 85:15 styrene:MAA



Good ${}^6\text{Li}$ solubility is paramount, so a variety of Li salts are being studied dissolved at different temperatures

PSD FOR DIFFERENT ${}^6\text{Li}$ SALTS




Advantages

- Good solubility of ${}^6\text{Li}$ salt
- Good stability

Disadvantages

- Difficult to produce
- Lower light output




Advantages

- Simple synthesis of ${}^6\text{Li}$ salt
- Good light output



Disadvantages

- mTP required for high LO
- Lower Figure of Merit



For commercial production we have proceeded with an aliphatic ${}^6\text{Li}$ salt

BASICS OF PSD PLASTIC CHEMISTRY




Co-monomer addition to main matrix element in order to dissolve ^6Li salt

SOLUBILITY OF ${}^6\text{Li}$ SALTS





High MAA content reduces light output - but lower MAA requires higher processing temperatures

LIGHT OUTPUT VS CO-MONOMER FRACTION




There is a critical mass fraction from which light output declines rapidly. This point has not been reached using MMA.

LIGHT OUTPUT VS CO-MONOMER FRACTION





There is a critical mass fraction from which light output declines rapidly. This point has not been reached using MMA.

PRIMARY DYE AS LIGHT ATTENUATOR WITH MAA





When using mTP as primary dye instead of PPO, critical point is for declining LO is not reached

BASICS OF PSD PLASTIC CHEMISTRY



Dyes used during the production may impact the long way stability of the plastics

STABILITY OF PLASTICS





■ initial
■ 2 years later

Plastics with ⁶LiPSA, ⁶LiBSA contain 85:15 PS:PMMA
Plastics with ⁶LiIBA contain 90:10 PS:PMAA


mTP and MDAC (actual antioxidant) show promising results regarding long term stability

STABILITY OF PLASTICS



Higher temperatures and air are clear reasons for early degradation.

HOME PRODUCTION OF PLASTIC AT LARGE SCALE PROVED CHALLENGING (TEMPERATURE, CONTROL ENVIRONMENT...)





Initial attempts to fabricate plastics at larger scale had defects, discoloration and opacity

FROM LAB TO COMMERCIAL PRODUCTION




External collaborator is consistently producing batches of 5.5x5.5x50 cm bars for testing

FINAL PRODUCT



External collaborator is consistently producing batches of 5.5x5.5x50 cm bars for testing



ROADSTR

A MOBILE
ANTINEUTRINO
DETECTOR

TESTING NEW PSD PLASTIC TECHNOLOGY

THE ROADSTR PROGRAM AT LLNL

Reactor Operations Antineutrino Detection Surface Testbed Rover


- ▶ Building from recent advances, our goals are to develop and demonstrate enabling technologies for mobile antineutrino detectors




ROADSTR

Areas of development


Background prediction



PSD Plastic Scintillators



Segmented geometries





Mobile deployment engineering



CHARACTERIZATION SETUP FOR COMMERCIALY PRODUCED BARS

Testing different wrappings




Collimator moves across the setup thanks to linear stage

- ▶ Hosts up to 4 segments with **double PMT** readout.
- ▶ Linear stage allows precise **position-scan**


Characterization setup allows for multi-bar testing using different collimated sources placed at varying positions remotely controlled

LINEARITY TEST USING DIFFERENT SOURCES




- ▶ Position scan displays long attenuation lengths ~ 80 cm
- ▶ Multi-source measurements show good linearity and effective light yield of ~ 500 - 600 PE/MeV

- ▶ After characterization, bars are stored in vacuum to avoid deterioration.
- ▶ Control bar left in contact with air to test stability of material




All bars tested to this moment have display consistent results in terms of attenuation length and light output

PSD CAPABILITIES USING CF252



- ▶ The plastics show excellent PSD capabilities.
- ▶ Clear and distinct n-capture island.
- ▶ Figure of Merit ~ 1.2 between nuclear and electronic recoils (work in progress)



Being able to

SUMMARY

- ◆ The **PROSPECT aboveground** detection is an important capability **demonstration** for reactor **monitoring applications** and other **reactor neutrino** studies
 - ◆ **Mobile** aboveground systems that maintain **high sensitivity** are a clear **next step** along the technology development path
-
- ◆ The **ROADSTR** program at the **LLNL** is **advancing** PSD Plastic Scintillator **technology** :
 - ➔ Different ^6Li salts (Aliphatic / Aromatic) , solubility monomers (MMA / MAA) and primary dyes (PPO/mTP, MDAC) considered
 - ➔ Plastic elaboration approach is extensible to large scale and it's been transferred for external production.
 - ➔ Long-term and stability effects on the plastics still under research.

