

Why I am excited about working on DAMIC-M in 10 minutes


Giorgos PAPADOPOULOS

DAMIC-M

LPNHE, Sorbonne University, Paris, France

Supervised by: Antoine Letessier-Selvon

for New Perspectives 2020



Dark matter introduction





Dark Matter


Not electromagnetically interacting

Gravitationally interacting like matter

- WIMP(s): Weakly Interacting Massive Particle(s)



DAMIC-M expected limits





Spin-independent DM-nucleon scattering cross section vs DM mass

Giorgos PAPADOPOULOS

Original plot from: *First results from the CRESST-III low-mass dark matter program, 2019, arXiv:1904.00498v1* and drawn line for DAMIC-M

Kinetic mixing parameter vs $m_{A'}$, assuming that the dark photon constitutes all of the DM



Plots from the DAMIC-M proposal in 2017.

DM-electron cross section vs m_χ for a light A' mediator ($m_{A'} \ll \text{keV}$)

DAMIC-M overview



To achieve these limits:

Massive detector

Very low threshold &
Single e resolution

Very low
background
(cosmic bg & radioactivity)

DAMIC-M overview



To achieve these limits:

Massive detector


Very low threshold &
Single e resolution

Very low
background
(cosmic bg & radioactivity)

DARk Matter In CCDs at Modane (DAMIC-M):


- Direct dark matter detection
- Low mass WIMPs and hidden sector DM
- Scientific grade **Charge-Coupled Devices** with a total target mass of $\sim 1\text{kg}$
- CCDs with Skipper readout implementation
- R&D of a novel acquisition system
- Radiopure materials for construction & shielding $\sim 0.1 \text{ events}/(\text{keV kg day}) = 0.1 \text{ dru}$
- Placed in Underground Laboratory at Modane

DAMIC at Modane - 2022




- ~2km of rock to stop cosmic bg
- Radon free air supply

Shielding & Background








DAMIC @ SNOLAB background = 11.8 dru
DAMIC-M background goal = fraction of 1 dru




DAMIC-M CCDs

Scientific-grade Charge Coupled Device (CCD) made of pure n-type Si

- 50 CCDs in a tower with a total target mass $\sim 1\text{kg}$
- Most massive CCDs ever built: 36Mpix large with a pixel area of $15\mu\text{m} \times 15\mu\text{m}$ and $675\mu\text{m}$ thick, $\sim 20\text{g}$ each
- 3D reconstruction of the incident point using the charge packet diffusion



CCD Operation




CCD single pixel.




- Charge collection under active electrode
- n-type Si: collected charge \rightarrow holes
- **Dark current**: thermally generated charge in the bulk of the silicon

Charge Transfer

- Move the charge by alternating the voltage of the electrodes (clocks) to the Readout circuit



- **Clock noise**: lose or gain charge if the clocks are not well defined



Skipper CCDs – sub- e^- resolution






- **Regular** CCD: single skip integration time $O(10\mu s)$

- high frequency noise is eliminated
- low frequency noise dominates ($1/f$ noise)


- **Skipper** CCD: single skip integration time $O(1\mu s)$

- multiple measurements of the pixel charge
- low frequency noise eliminated
- single measurement of low resolution


- Output noise decreases as $1/\sqrt{NDCM}$ (Non-Destructive Charge Measurements), reaching sub- e^- resolution



Pixel-charge
distribution
of the whole
CCD



New acquisition system




CROC: CCD ReadOut Chip

- Low noise
- Amplifies and processes the output of the CCD to improve the SNR
- Minimizes any introduced noise until the ADC

ADC: Analog to Digital Converter

- High resolution
- Fast sampling



CABAC: Clocks And Biases ASIC for CCD


- Provides the necessary clocks and bias voltages for the CCD operation
- Performs the sequencing of the clocks

Timeline



Activities:



- Background studies
- Large CCD packaging
- **R&D of the new electronics**
- **Production of the sequencer for the CCD operation**
- **Operate the CCD with the new acquisition system**




Low Background Chamber (LBC): Installation of a smaller detector with ~25g of CCD at LSM.

Objectives:

- characterization of DAMIC-M CCDs (dark current).
- Test the new electronics and the overall acquisition system.
- Measurements of background at LSM.
- First scientific results.
- Start operation in 2021



... *STAY TUNED*





References :


[1] *DAMIC-M Experiment: Thick, Silicon CCDs to search for Light Dark Matter*, N. Castello-Mor for the DAMIC-M Collaboration, 2020

Extra slides

CCD readout circuit



Giorgos PAPADOPOULOS




Reaching the end of the CCD, there is a circuit to convert the pixel charge into voltage.

- The Reset Gate sets the Sense Node at a voltage reference value. This will cause a bump in the output signal which will decay quickly, resulting in an outcome reference level *around* V_{ref} .
- The charge Q is injected to the SN changing the voltage by $V_Q = Q / C_S$, where C_S is the capacity of the sense node which is known.
- Measure and subtract the reference and signal levels to find the V_Q .

CCD noise sources

Reset or kT/C noise

- After reset pulse thermal noise is generated by the resistance of the reset FET. The small capacitance of the Sense Node \sim fF leads to a significant uncertainty of the reference level.
- *Correlated Double Sampling* (CDS): measure both the reference and signal levels and subtract them to eliminate the reset noise.



Dark current


- Thermally generated electrons in the bulk of the CCD
- Linear dependence on time \rightarrow limits the exposure duration. The longer the exposure, the worse the Signal to Noise Ratio.
- Lower the temperature (\sim 100-140K) to decrease the dark current

Flicker or $1/f$ noise


- Source: generated traps in the output MOSFET
- The faster the readout frequency of the CCD, the less the contribution of the flicker noise.
- Dominant up to \sim 0.1MHz readout speed

White noise

Thermal noise generated by the output amplifier MOSFET.





Sequencer for DAMIC-M CCDs



Schematic of DAMIC-M CCD

- The total readout time increases linearly with the skips per pixel
- **Dark current!** (thermal noise generated in the silicon bulk of the CCD) limits the exposure period of the CCD weakening the Signal-to-Noise Ratio (SNR)
 - DAMIC-M CCDs have 4 readout circuits to decrease the total readout time
 - Precise signals (clocks) move the charge in the most efficient way




Examples of clocks

New Electronics

The CCD is placed in a cryostat and is controlled and readout by external electronics.

- All voltages and clocks during the expose and readout phases will be provided by the **Clocks And Biases ASIC for CCD (CABAC)** board.
 - A **sequencer** implemented in the software will define the 4CABAC board output for the control of the CCD and the CROC.
- **CCD ReadOut Chip (CROC)**: amplifies and processes the signal to improve the Signal-to-Noise Ratio.
- **Analog to Digital Converter (ADC)**: performs the transition from the analog to the digital domain.
- Everything is controlled by the **Online Digital Interface for Low-noise Electronics (ODILE)** motherboard.



CROC: Transparent mode

The CROC operates as a simple single-to-differential gain amplifier. The output signal shape will be similar to the CCD's, just amplified.


Basically, the ADC oversamples the reference and signal levels.

Advantages

- Digitally determination of the reference and signal level by averaging a sufficient number of samples → *Digital CDS* (DCDS)
- Further digital analysis is possible.

Challenges

- Large number of data to process with Firmware and later on in analysis.



CROC: DSI mode

The DSI is the dominating mode to be used for the pixel charge measurement. The DSI method combines a *Correlated Double Sampling* and a CCD signal integration.

- 1) A **reset pulse** sets the CROC input to a voltage reference. Same principle as for the CCD conversion of charge.
 - 2) As the reference level stabilises, the CROC amplifies and **integrates** this level for an integration time t_{int}
 - 3) The CROC input is isolated while the pixel charge is injected to the Sense Node of the readout circuit.
 - 4) When is stable, the signal level is **integrated** for the same integration time with **reversed polarity** with respect to the reference level (achieving the CDS)
 - 5) The **ADC measures** the output of CROC.
- New measurement with a new **reset pulse**...

Reset → measure reference → measure signal → Sample with ADC

