

Deformation Mechanism for Polycrystal Niobium at Cryogenic Temperature

Saravan Chandrasekaran, Payam Darbandi,
Derek Baars, Neil Wright, Farhang Pourboghrat,
Thomas Bieler

Michigan State University

Chris Compton
National Superconducting Cyclotron Laboratory

Ahren Kolka, Terry Grimm,
Niowave, Inc.


Supported by DOE (ILC) and Fermi National Laboratory




Design and Fabrication



- Use available ATS Creep-Stress Relaxation Machine
- Design adapted from cryogenic system developed at FSU/National Magnet Lab, Tallahassee, by Bob Walsh
- Dewar designed and built by *Niowave, Inc.*




Clevis hook is on bottom of inner Dewar chamber





Yes, it is not very well aligned here


Polycrystalline samples deformed at 77 and 4K agree with data from literature




- High RRR Nb has same yield and flow behavior at 77 K
- At 4K, Sample showed 5 instances of jerky flow before fracture, at lower strain than samples from literature




Tensile fracture features



- At 300 K, no fracture
- At 77K, fracture involved considerable necking, typical ductile failure features with perpendicular fracture
- At 4K, multiple shear bands observed; one caused shear fracture.




Polycrystalline Nb, tensile test @ 4K





Many mechanical twins
observed, (arrows)
as well as deformation
gradients in grains,
visible as color gradients

1 μm step size between data points





One of the family of 112 plane traces align with twins,
supports assertion of twins
(112 are twin planes for Nb)



Future plans

- ***System modifications***
 - ***Initial results are positive compared to literature***
 - ***Improve He transfer, bayonet location***
 - ***Bottom grip alignment, and retrieval***
 - ***Calibration***
- ***SRF materials test program***
 - **Test materials**
 - **Parallel testing by collaborators**
 - **Data collection and engineering documentation**
 - **Analysis of slip systems, shear banding**

Future plans

- ***Initial materials and joints to be evaluated***

- **High purity niobium (poly-crystal)**

- **Large grain niobium**

- **Single crystal niobium**

- **Titanium**

- **Nb-Ti Alloy**

- **Niobium to Nb-Ti joint**

- **Nb-Ti to Titanium joint**

- **Niobium to stainless steel joint**

In addition, MSU's SRF materials science program will use cryogenic testing system for synergistic experiments, studying dislocation behavior at cryogenic temperature **and the effects on cavity performance (e.g. tuning).**