





Vertical cavity testing at INFN

Angelo Bosotti/ INFN Milano – Lab. LASA PIP-II Technical Workshop: CAVITY PROCESSING AND TESTING 02/12/20

A Partnership of:

US/DOE

India/DAE

Italy/INFN

UK/UKRI-STFC

France/CEA, CNRS/IN2P3

Poland/WUST




Fabrication activities at LASA – INFN Milano

- INFN LASA has a long experience on cavity design and, in collaboration with industry, in fabrication of cavities
 - Copper cavities for CS (Superconducting Cyclotron) at LNF
 - Collaboration with CERN for Nb sputtering of 352.2 MHz LEP copper cavities
 - Construction and test of four cell SC Niobium prototype cavity for ARES/LISA at 500 MHz (~ 1990)
 - Collaboration with **DESY** for the first **TTF** cavities
 - Collaboration with LANL (Advanced Accelerator Applications, 350 MHz) and FNAL (HINS, 325 MHz) for the construction of SC Spoke cavities
 - We have significantly contributed to the design of the SNS cavities at 805 MHz
 - TRASCO cavities were designed at LASA and fabricated at 704.4 MHz
 - LASA was deeply involved in the mass production of the 800 cavities for XFEL at 1.3 GHz
 - 20 3.9 GHz cavities for the third harmonic module of XFEL were designed at LASA, fabricated and tested
 - 38 704.4 MHz cavities for the Medium Beta Section of the European Spallation Source
 - 2 650 MHz prototype cavities for the Low Beta Section of PIP-II in preparation for the 38 cavities inkind contribution



Cavity construction and preparation overview (Borrowed from: Claire Antoine CAS Erice)



02/12/20


INFN - LASA ESS cold test infrastructure

- **Residual magnetic field**: < 8 mGauss. Single μmetal external shield, second cryogenic shield (Cryoperm) in progress.
- **Subcooling system**: rotary vane pumps + roots pumps. Lowest temperature 1.5 K. Cooling power: ~ 40 W @2 K
- Dedicated cold vertical insert for ESS cavities with several diagnostics: **second sound** detectors for quench localization, cryogenic photodiodes, fast thermometry, flux gate.
- X-ray counter and X-ray Nal spectrometer available.
- **RF** power system, Qualified Slow Pumping Slow Venting (SPSV) system, Clean Room, Ultra Pure water System, 🖟 **HPR**

15 1.8 Temperature (K) Angelo Bosotti | PIP-II Technical Workshop

VT4

VT6



Cooling power vs. temperature

Summary of LASA VT facility characteristics


- Test capability for SC cavities with f > 500 MHz
- Control Electronics (PLL) and Power Amplifiers
 - 500 < f < 900 MHz, 500 W
 - 1.2 < f < 1.4 GHz, 500 W
 - 3.5 < f < 3.95 GHz, 200 W


Cooling Power ~ 40 W @2 K

- Lowest temperature = 1.5 K
- Maximum accelerating gradient measured E_{acc} = 38 MV/m@2K



Connection to SPSV





Cavity on Insert with sensors installed


Cavity Installed On Insert








Inserted in Vertical Cryostat





Helium transfer from Dewars to Vertical Test Cryostat





02/12/20

INFN-LASA infrastructure upgrades

INFN cold test infrastructure at LASA is being upgraded.


- Cylindrical cryo-perm inner shield ordered in order to halve the currently measured 8 mG average remnant field in the cavity equator region.
 - Test installation successfully done at LASA, heat-treatment done
- Development of active and dynamic local magnetic field cancelling through combined use of Helmholtz's coils and flux-gate sensors
 - Setting almost zero residual magnetic field when SC transition occurs
- Boost in cryogenic plant performances:
 - Higher cryogenic power, up to 70 W at 32 mbar
 - Refilling at 2.0 K option ordered, to extend cavity testing time by means of counter-flow heat-exchanger followed by a Joule-Thomson expander.
 - Faster cool-down rate, now at about 1-1.5 K/min














Angelo Bosotti | PIP-II Technical Workshop

Temperature Sensors

DT-670-SD-1.4L Silicon Diode

- Main Use to monitor cooldown to 4.2K
- Installed on the insert bottom plate
- Trange 1K < T < 325 K
- From calibration curve 1<T<20K δ T < 10 mK (4.2 K δ T=2mK; 2K δ T=0.07 mK!)

Cernox thin film resistance cryogenic temperature sensors

- Placed on cavity cells
- Used for Fast Thermometry

CCS Carbon Ceramic Sensors

- Installed on cavity cells for Fast Thermometry
- Installed along the insert for Standard Thermometry

PT1000

Installed along the insert for Standard Thermometry

Vapor Pressure T < 4.2 K

- E.G.: T = 2K vp = 32 mbar
- Sensitivity < 0.1 mbar
- $\Delta T \approx 50 \text{ mK}@2\text{K} \Delta p \approx 4.5 \text{ mbar}$

Diode & Standard Thermomentry

Lakeshore 224 Temperature Monitor

Fast Thermometry

- (Home-made) Custom Electronics
- 10 100 μA FET Current Generator
- Instrumentation Amplifier



Vertical Test Protocol

System Calibration (VNA + PM)

- $\square A_1$, A_R , A_T (S_{21} , RT)
- \Box G_I, G_R, G_T (S₁₁, 4.2K and 2K)
- $\square C_1$, C_R , C_T (S_{21} , RT)
- ☐ Superfish: G, R/Q, L

Subcooling

- **>**Acquired
 - T, P_I , P_R , P_T , f_{π} , τ_{VT}
- **≻** Computed
 - P_C, Q₀, R_S


Cavity Qualification: Q₀ vs E_{acc}

- ☐ Calibration @ 1 MV/m < E_{acc} < 2 MV/m
 - \clubsuit Acquired : P_I, P_R, P_T, f_{π}, τ _{VT}
 - **Computed:** P_C , Q_0 , E_{acc} , $K_E = \frac{E_{acc}}{\sqrt{P_T}}$
- □ Power Rise → P_I raised via digital step attenuator
 - \clubsuit Acquired: P_I , P_R , P_T , f_{π} , τ_{VT}
 - \bullet Computed: P_C , Q_0 , $E_{acc} = K_E \sqrt{P_T}$




ESS MB Cavity Vertical Test QvsE at T=2K







M001 - Resonance frequency variation vs He bath pressure




Examples of RF Test Results



MB001 HeTank f vs Eacc2 @ T=2K




EZ_SCCFG001 Vertical Test @ T=2K Preliminary Data (12/01/2020) 1/2



Q ₀ Low Field	3.32x10 ¹⁰
Max E _{acc} [MV/m]	30.5
Q ₀ @17 [MV/m]	2x10 ¹⁰
P _{diss} [W]	4.7
Q ₀ @Max E _{acc}	4x10 ⁹




EZ_SCCFG001 Vertical Test @ T=2K Preliminary Data (12/01/2020) 2/2




π@10.1 MV/m 3π/6 @ 9.7 MV/m 5π/6 @ 12.0 MV/m r=110, q=310° z=30 r=112, q=200° z=-276

Second sound reconstruction of the 6 passband modes quench




Photodiode signals vs Eacc, labelled with corresponding cavity irises, and external radiation level

Examples of Diagnostic Results



Scintillation spectra at quench field before and after conditioning



Cernox sensor during quench at 22 MV/m

