

FRIB cryomodule review 16-18 August 2011

Tom Peterson

22 Aug 2011

People

- Reviewers
 - John Hogan, Jlab
 - Tom Peterson Fermilab
 - Joe Preble, ITER (France)
- FRIB personnel (partial list)
 - John Weisend (Cryogenics & Cryomodules Department Manager)
 - Matt Johnson (Mechanical Engineering Group Leader)
 - Shelly Jones (Cryodistribution Group Leader)
 - Also -- Jie Wei (Accelerator Systems Division Director), Dan Stout (Chief Engineer), and ~8 mechanical engineers and designers




Acquisition: Cryomodule Assembly [1]

Inventory/QA



Assembly

- 2 cryomodules/month assembled in industry
 - 1 cryomodule/month/line
 - 2 assembly lines
- Cryomodule design used in both FRIB and ReA3 projects




Facility for Rare Isotope Beams
U.S. Department of Energy Office of Science
Michigan State University



C. Compton, 28 July 2010, B05, Slide 15



e-Linac top-load box concept




- Cold mass (cavity string, tuners) supported from strongback
- Strongback held in place by support posts strung from the lid






$\beta=0.53$ Preliminary Design






$\beta=0.53$ Lower Plate Assembly





Cold Mass Assembly Installation onto Bottom Plate

Cryogenic & Vacuum
Vessel Talk 07 by T. Nellis



FRIB



Facility for Rare Isotope Beams
U.S. Department of Energy Office of Science
Michigan State University

M.J. Johnson, 16 Aug 2011, Cryomodule Peer Review - 04, Slide 11



Benefits [1]

- **Cold mass assembly**
 - Less risk of damage to FPC and tuner as opposed to dropping entire assembly with shielding into vessel
 - Easier to attach tuners; nothing to restrict access
- **Simplified alignment & positioning of components**
 - ReA3 alignment process took 1 week where this dowel fit assembly eliminates that step
- **Longer and wider bottom plate**
 - » More room for orthogonal positioners/feet
 - » Lower center of gravity
- **Safer; personnel not under hanging assembly**
- **MLI easier to manage and not hanging in the way during assembly**



Benefits [2]

- **μ -metal shield**
 - Reduced part count
- **Thermal shield**
 - Aluminum 1100-O material savings
 - Simplified fastening with rivets
 - Dedicated cooling line removes soldering braids to sheet metal
 - No taping necessary
- **Cryogenic headers**
 - Attached to rails removes hanger rods which reduces heat load
 - Piping assembled and field welds done without MLI concerns
- **Vacuum vessel**
 - Bottom plate easily machined
 - Alignment accomplished before bell jar assembled
 - Sets on G10 legs/feet with no hanger rods to bring in heat
- **Fewer assembly fixtures**
 - No assembly stand needed for building therefore multiple modules can be assembled at the same time

