


Metal-loaded Liquid Scintillator

Liangming Hu
Virginia Tech, Blacksburg, Virginia
Chemistry Department, Brookhaven National Laboratory
Upton, New York

The Trend of Neutrino Detector



What do we need from M-LS?



- Preparation of high-quality M-LS must be Reliable and Reproducible: **long-term stability** and **long attenuation length with suitable photon-production**
- **At BNL:**
 - Solvent-extract organometallic compound into LS with carboxylic acid, RCOOH
 - Study effects of inclusion in organic phase of OH^- , H_2O , free carboxylic acid, Cl^-
 - Characterize how parameters affect light yield, chemical stability, final metal ions dissolved in LS, and chemical composition
 - Develop a variety of chemical techniques for chemical/radioactive purifications of all starting materials, which is the key of clean M-LS
 - Remove the U/Th/K from the starting materials to increase the sensitivity

M-LS Criteria for Neutrino Experiments

- *Long-term Stability: > 3 years*
- *Long attenuation length: > 10 m*
- *High photon yield*
- *Low radioactive background*
- *ESSH*

Components of LS

- ❖ **Aromatic solvent** that contains a high density of π -electrons for energy transfer
- ❖ **Fluor** that transfers the energy (<400 nm) to light (>400 nm) within the optimal detection range of PMT



Metal selection for different experiments

- *Nd for SNO+*
 - *Serve as a double-beta decay target*
 - *Large $Q(3.37 \text{ MeV})$ and favorable matrix element*
- *Gd for Daya Bay*
 - *Enhance neutron-capture cross section*
 - *Shorten neutron capture time*
 - *A high release energy from capture, good for suppressing background*
- *In for LENS*
 - *Low threshold*
 - *Directly measures neutrino energy*
 - *Triple tag effect*

Selection of Liquid Scintillator

- *High density, flash point, low toxicity, and low cost*
- *Chemical compatibility*
- *High light yield and long attenuation*
- *Able to load organometallic compound*

Study of Liquid Scintillator

	<i>Gd Loading</i>	<i>d</i> (g/cm ³)	<i>UV Abs⁴³⁰ before / after</i>	<i>Abs₂₆₀</i>	<i>n²⁰</i>	<i>Light Yield</i>	<i>H atoms[‡] per c.c</i>	<i>Flash Point</i>
PC	<i>Yes</i>	0.889	0.008 / 0.002	2	1.504	1	5.35×10 ²²	48 C
PCH	<i>Yes</i>	0.95	0.072 / 0.001	1.7	1.526	0.46	5.71×10 ²²	99 C
DIN	<i>Yes</i>	0.96	0.040 / 0.023	>10	-	0.87	5.45×10 ²²	>140 C
PXE	<i>Yes</i>	0.985	0.044 / 0.022	2.1	-	0.87	5.08×10 ²²	167 C
LAB	<i>Yes</i>	0.86	0.001 / 0.000	1	1.482	0.98	6.31×10 ²²	130 C
Mineral Oil <i>C₂₄~C₂₈</i>	<i>No</i>	0.85	0.002 / 0.001	1	~1.46	~	6.73 – 8.00 ×10 ²²	215 C
Dodecane	<i>No</i> (<20%)	0.75	0.001 / 0.000	1	1.422	~	6.89×10 ²²	71 C

M. Yeh et. al Nuclear Instruments and Methods in Physics Research Section A: Gadolinium-loaded liquid scintillator for high-precision measurements of antineutrino oscillations and the mixing angle, 013 Volume 578, Issue 1, 21 July 2007, Pages 329-339



LAB Specification

LAB is attractive:

- *High flashpoint*
- *Biodegradable*
- *Millions of tons of it are produced annually for detergent industry*

linear alkyl chains of 10-13 C atoms with a benzene ring; used primarily for the production of biodegradable synthetic detergent

Boiling Point (°C)	275 - 307
Melting Point (°C)	< -50
Flash Point (°C)	130
Vapor Pressure (mmHg)	< 0.1 mmHg @ 20°C
Vapor Density (Air =1)	8.1
Solubility in Water	Insoluble
Molecule Weight	233 - 237 g/mol
pH	Not applicable
Viscosity	5 - 10 cps @ 20°C
Evaporation Rate (water =1)	Not applicable



Selection of Extractant

Extractant	Gd form in LS	Comparison
alcohols	$\text{GdCl}_3 \cdot 6\text{H}_2\text{O}$	GdCl_3 quickly dissolved in the mixture of alcohol and PC; low light yield and not stable possibly due to quenching effect and high vapor pressure .
P=O compounds	$\text{Gd}(\text{carboxylate})_x \cdot (\text{Cl})_y \cdot (\text{OH})_z \cdot (\text{H}_2\text{O})_a \cdot (\text{TOPO})_b$	high extraction efficiency; moderate attenuation length; not stable for long term (phosphorus might interact with other compounds; CHOOZ experience of NO_3)
carboxylic acid	$\text{Gd}(\text{carboxylate})_x \cdot (\text{Cl})_y \cdot (\text{OH})_z \cdot (\text{H}_2\text{O})_a$	high extraction efficiency; long attenuation length; high light yield; very stable (>14 months for Gd-LS and over 2.5 years for In-LS since synthesis)

Selection of Carboxylic Complexing Ligands

CARBOXYLIC ACIDS FOR LENS YLS

WATER SOLUBLE ↑ ↓ WATER INSOLUBLE	<chem>CC(=O)O</chem> 2C ACETIC (AcA)[60]	<chem>CCC(=O)O</chem> 3C PROPIONIC (PA)[74]	<chem>CC(C)C(=O)O</chem> 4C ISOBUTYRIC (IBA)[88]	<chem>CCCC(=O)O</chem> 4C BUTYRIC (BA)[88]
	<chem>CC(C)CC(=O)O</chem> 5C ISOVALERIC (IVA)[102]	<chem>CC(C)(C)C(=O)O</chem> 5C TRIMETHYLACETIC (TMAA)[102]	<chem>CC(C)CC(=O)O</chem> 5C METHYLBUTYRIC (MBA)[102]	<chem>CCCCC(=O)O</chem> 5C VALERIC (VA)[102]
	<chem>CC(C)CC(C)C(=O)O</chem> 6C 2METHYLVALERIC (MVA)[116]	<chem>CCC(C)CC(=O)O</chem> 6C ETHYLBUTYRIC (EBA)[116]	<chem>CC(C)C(C)CC(=O)O</chem> 6C 2,2DIMETHYLVALERIC (DMVA)[130]	<chem>CCCCCC(=O)O</chem> 6C HEXANOIC (HxA)[116]
	<chem>CC(C)CCCC(=O)O</chem> 8C ETHYLHEXANOIC (EHA)[144]			<chem>CC(C)C(C)CC(C)C(=O)O</chem> 9C TRIMETHYLHEXANOIC (TMHA)[158]

*Different carboxylic acids
for different metal ions*

Loading concentration



Loading efficiency

Light yield


Synthesis of M-LS

Solvent Extraction vs. Solid dissolution

LAB + Carboxylic acid (in H₂O) + MCl₃ (in H₂O) Carboxylic Acid (in H₂O) + MCl₃ (in H₂O)



Remove water layer



Collect the solid

Wash

Dissolve the solid in LAB


Wait for it to get cleared

Leach out the additional water

Nd-loaded LS for SNO+

1-k tons of 0.1% Nd in Liquid Scintillator

- Neutrinoless double beta decay (^{150}Nd)
- Determine the mass/nature of the neutrino



"rope basket"

Acrylic vessel



SNO's ultra-pure water systems will be replaced by similar purification systems that can eliminate trace radioactivity from an organic liquid scintillator

Gd-loaded LS for Daya Bay

200 ton 0.1% gadolinium-loaded liquid scintillator (Gd-LS)

Measure reactor $\bar{\nu}$ for θ_{13} at 1%

Gd-LS was produced in multiple batches but mixed in reservoir on-site, to ensure identical detectors.



Detectors in Hall 1


In-loaded LS for LENS

125 tons of ~8% ^{115}In Liquid Scintillator for full scale LENS



- The real time primary low energy (sub-MeV) solar neutrino spectrum
- Solar metallicity and luminosity



A view inside KURF from above microLENS liquid handling





Purification of Water and TMHA




Purification of HMVA and LAB

- Automatic distillation of HMVA
- Dry column purify LAB




M-LS Characterization (I)

- $L_{1/e}$ (att. length) by 2-m dual-beam, vertical LED system.



$$\mathcal{L} = \frac{\log(e)L}{A(L)}$$


Extinction of LED525E Light in 18MΩ cm H₂O




18.9±1.2m for 18MΩ H₂O at 525nm, [J. Goett](#)

L. Hu BNL Chem

- Light Yield (S%)



Light Yield Percentage Calculated Program



- $[M^{n+}]$ by XRF and UV



M-LS Characterization (III)



IR
Qualification and quantification




Fluorescence Spectrometer
Excitation, Emission, and lifetime of LS

M-LS Characterization (IV)



GC/MS
Impurities of chemicals



LC/MS
Materials compatibilities

Summary

- *M-loaded LS becomes one of main-stream detection mediums from the past 5 years.*
- *BNL is one of the facility that has the expertise and equipments for all-aspect development of organometallic liquid scintillator including (1) synthesis, (2) characterization and (3) purification of M-LS.*
- *A variety of metallic ions has been loaded into liquid scintillator at different concentrations (0.1 – 10%) with high-quality, large-scale production (> hundreds of tons) of M-LS for different neutrino experiments*
 - *M-LS are stable for long period of time (>3.5 yrs for 10% In-LS; >2 yrs for 1% Nd-LS; and >3 yrs for 0.1% Gd-LS).*
- *M-LS use of veto or calibration are under development.*

Acknowledgement

Dr. Minfang Yeh, PI

Dr. Sunej Hans

Dr. James Cumming

Dr. Pankaj Sihna

Chemistry Department, BNL

Richard Rosero

Wanda Beriguete

Bonnie Chan

Prof. Raju Raghavan

Prof. Bruce Vogelaar

Physics Department, Virginia Tech

Research sponsored by the U.S. Department of Energy, Office of Nuclear Physics and Office of High Energy Physics, under contract with Brookhaven National Laboratory – Brookhaven Science Associates.