

Gadolinium in Water: Zen and the Art


禪

Mark Vagins
IPMU, University of Tokyo

ANT 2011, Philadelphia
Oct. 11, 2011

גדוליניום

“Gadol” = Great!





In 2003, John Beacom and I put out the original
GADZOOKS!

(**G**adolinium **A**ntineutrino **D**etector **Z**ealously
Outperforming **O**ld **K**amiokande, **S**uper!) paper.

It proposed loading big WC detectors, specifically Super-K,
with water-soluble gadolinium, and evaluated the physics
potential and backgrounds of a giant antineutrino detector.

[hep-ex/0309300, Beacom and Vagins, *Phys. Rev. Lett.*,
93:171101, 2004]

Here's what the coincident signals in Super-K with 0.2% of GdCl_3 or $\text{Gd}_2(\text{SO}_4)_3$ will look like (energy resolution is applied):



spatial and temporal
separation between
prompt e^+

Cherenkov light and
delayed Gd neutron
capture gamma
cascade:

$$\lambda \sim 4 \text{ cm}, \tau \sim 30 \mu\text{s}$$

→ A few SN events/yr
in Super-K with Gd

In addition to our two **guaranteed** new signals, SN and reactor, adding gadolinium to SK will provide a variety of other interesting possibilities:

- Sensitivity to very late-time black hole formation
- Full de-convolution of a galactic supernova's ν signals
- Early warning of an approaching SN ν burst
- (Free) proton decay background reduction (5X)
- New long-baseline flux normalization for T2K
- Matter- vs. antimatter-enhanced atmospheric ν samples

All of this could work even better in an much larger detector.



Indeed, such a massive new project will need to have some new physics topics to study!

To make GADZOOKS! work, we will have to:

Dissolve the gadolinium sulfate in the water

→ Easy and fast (pH control)


Remove the gadolinium efficiently and completely when desired

→ Also easy and fast (pH control)


Keep pure water pure yet retain gadolinium in solution

→ The tricky part; need a selective Gd filtration system


Over the last eight years there have been a large number of Gd-related R&D studies carried out in the US and Japan:




Detector Tank and Pump 100 gpm
250,000 gallons High Purity Water and GdCl3



UCI Gd Removal System






Gd Filter Press Removal System; January 5th, 2011



Adding 383 grams $\text{Gd}_2(\text{SO}_4)_3$ to 191 liters of H_2O ; January 5th, 2011

**WHY DID THE WHITE BEAR DISSOLVE
IN WATER?**



BECAUSE IT WAS POLAR.

**I WOULD MAKE ANOTHER
CHEMISTRY JOKE**



**BUT ALL THE GOOD ONES
ARGON**




Resulting solution is rather cloudy; January 5th, 2011




After treating with H_2SO_4 , solution is completely clear; January 5th, 2011



Precipitate forms after raising pH to 10 with NaOH; January 5th, 2011
This is concentrated by ultrafiltration and forced through a filter press.



Wet $\text{Gd}(\text{OH})_3$ after passing through filter press; January 6th, 2011




One day later, $\text{Gd}(\text{OH})_3$ is dry and has crystallized; January 7th, 2011



The resulting dried $\text{Gd}(\text{OH})_3$ precipitate; January 2011.

In highly schematic form, we would like a water system with selective Gd filtering to work something like this:



Final Polish
(Gd Trapping)

Gd Bypass
(Gd Filtering)

1st Stage Cleaning
(Gd Passing)


Detector Tank

Membrane-based Filtering Technologies




Microfiltration

1,000 – 100,000 angstroms
membrane pore size




Ultrafiltration

100 – 1,000 angstroms
membrane pore size




Nanofiltration

10 – 100 angstroms
membrane pore size




Reverse Osmosis


5 – 15 angstroms
membrane pore size




"Band-pass Filter" - 2007



“Band-pass Filter” - 2009



Prototype Selective Filtration Setup @ UCI



Membrane
Pre-Flush

Nanofilter #1


Nanofilter #2

Reverse
Osmosis

Ultrafilter


We've built a new, dedicated Gd test facility, complete with its own water filtration system, 50-cm PMT's, and DAQ electronics.

This 200 ton-scale R&D project is called **EGADS** –
Evaluating **G**adolinium's **A**ction on **D**etector **S**ystems.




EGADS Facility

**In June of 2009
we received
full funding
(390,000,000 yen
= ~\$4,300,000)
for this effort.**



Hall E and EGADS

12/2009



2/2010



6/2010



12/2010


5/2011



2/2011


Hall E and EGADS

EGADS “Band-Pass” Filter - 2011





Selective filtration system in Hall E; early 2011.






Dumping first batch,
28 kg, of $\text{Gd}_2(\text{SO}_4)_3$
into 15-ton
pre-treatment tank
on August 1st, 2011.



After recirculating through the pre-treatment system's 3 micron and 0.2 micron filters @ 1.5 tons/hr overnight, we put the Gd water into the main EGADS system at 17:48 on August 2nd.


EGADS Selective Filtration System

Oct. 2011



Cherenkov Light Remaining at 20 m (200-ton tank)

— Top — Center — Bottom × SK



Our pure “band-pass” water is as good as Super-K's best water after 15 years of tuning and adjustments!

On day 1, we were already up to 61% for the Gd-loaded water in the 15-ton tank.

This should be compared to 79% for “perfect” pure water.

[See Andrew Renshaw's talk]

EGADS Schedule

- 2009-10: Excavation of new underground experimental hall,
construction of stainless steel test tank and
PMT-supporting structure (all completed, June 2010)
- 2010-11: Assembly of main water filtration system (completed),
tube prep (completed), mounting of PMT's,
installation of electronics and DAQ computers
- 2011-13: Experimental program, long-term stability assessment

At the same time, material aging studies will be carried out in Japan, and
transparency and water filtration studies will continue in the US

**The goal is to be able to state conclusively whether or
not gadolinium loading of Super-Kamiokande will be
safe and effective.**

Target date for decision = 2012



Four weeks ago, the official Hyper-Kamiokande Letter of Intent appeared on the [arXiv:1109.3262](https://arxiv.org/abs/1109.3262)

1.0 Mton total water volume
0.54 Mton fiducial volume

Gadolinium loading is part of the executive summary.

