Status of NOvA

NuMI Off-axis v_e Appearance


Luke A. Corwin
Indiana University
Advances in Neutrino Technology
Philadelphia, PA - 2011 Oct. 10






Outline


- Brief Experimental Overview
- Scintillator
- PVC **Extrusions**
- Avalanche **Photodiodes** (APDs)
- Schedule




ANL, Athens, Caltech, Institute of Physics of the Czech Republic, Charles University, Czech Technical University, FNAL, Harvard, Indiana, Iowa State, Lebedev, Michigan State, Minnesota/Duluth, Minnesota/Twin Cities, INR Moscow, South Carolina, SMU, Stanford, Tennessee, Texas/Austin, Tufts, Virginia, WSU, William and Mary

NOvA Experiment Overview









Physics Goals


- Observe v_e
 Appearance
 - Measure θ_{13}
 - Determine Mass Hierarchy
 - Measure δ_{CP}
- Need high resolution (low density) and high mass








To 1 APD pixel Detector Elements







 PVC Cells are filled with liquid scintillator and grouped into alternating planes



Near Detector

- 220 tons
- Will be placed in a new cavern attached to the current MINOS cavern
- Characterize beam before oscillations








Near Detector On the Surface (NDOS)

- Prototype built to the original design of the near detector
- Instrumented, operational and taking data for 1 year
- Results
 - Taught us many lessons
 - Several design and procedure change
 - No broken fibers





Mixing The Scintillator (3×10⁶ gallons)





Pseudocumene (4.98%)






Delivered from China in ISO tanks

Wave Shifting Powders PPO (0.110%)bis-MSB (0.00153%)

6000 gallon stainless steel fluor blend tank



Stadis-425 (0.0010%)


Mineral Oil (94.91%)



Two 120,000 gallon epoxy lined fluor blend tanks

storage tank cleaned and holding our oil





Have enough of everything except mineral oil and pseudocumene for far detector


Hired private contractor (Renkert Oil) to deliver mineral oil and mix ingredients





Scintillator Quality Control

- Light Yield
 - Use radioactive sources to verify sufficient scintillator light
- Clarity tested using a commercial tintometer
 - UV spectrophotometer
- Verify correct chemical composition.
 - Done at Indiana Univ.
 Chemistry Dept.








Module Assembly


- Many pieces must be brought together to form an active detector module
- Cell interiors must be very reflective so scintillation light is not lost.





Manifold Issues


- Manifolds have developed cracks (22%)
 - Splinted the NDOS manifolds
 - Redesigned manifolds to remove stress points for near and far detectors







PVC Extrusions





- PVC extruded through die to form 15m extrusions
- ~24,000 required for Far Detector.
- Currently have ~2300 useable extrusions in hand.




PVC Reflectivity Issues

- We require predicted light yield to the APD to be ≤14.6% of a perfect reflector.
 - Achieved using anatase TiO₂ in PVC
- Low reflectivity in some batches correlated with high fraction of rutile TiO₂
 - Requested <2% rutile contamination, and so far that is what we have received.



PVC knitting issues


- PVC knitted is less than ideal
- Ongoing iterations with manufacturer greatly improving results
 - No voids found in extrusions, so they are still useable




Extrusion samples are often cracked in QC testing, revealing smooth regions in the cross-section, such as the central region in this example, that are not ideally knitted.










Scintillation light travels along wavelength shifting fibers to end of manifold


Light detected in by avalanche photodiodes (APDs) that are sealed, cooled (to -15 °C) and mated to the detector data acquisition system.



APD Performace

- Quantum Efficiency of 85%
- Gain of 100
- Low Dark Current
- NDOS has taught us much about installing them.









APD Noise Issues

- We have received a total of
 - ~420 APDs for the NDOS
 - ~150 of them are still working
- Causes
 - Dirt and oil
 - Corrosion
 - Contact with fibers
 - Poor seals: condensation or _____ ice when cooled
 - Installation Errors
- Rearranging surviving APDs








APD Potential Solutions

- "Cable-ectomy"
 - Remove cable from noisiest pixel
 - Sometimes successful in reducing noise on neighboring pixels
- Attempting to clean/repair some non-functioning APDs
- Coated APDs
 - Did not order APDs with coating because the standard coatings produced optical cross-talk
 - In discussions with manufacturer to produce APDs with protective coatings that will avoid cross-talk
 - Testing coatings (silicone and parylene) NDOS APDs




First Neutrino Data!







First Neutrino Data!




http://www-nova.fnal.gov/plots_and_figures/

Finding the Beams





Data in time





Schedule

- Tevatron shutdown on Sep. 30, 2011
- First large scale fluor blend later this month
- Ready to begin FD construction Jan. 2012



- Accelerator shutdown begins Mar. 2012
- ND cavern excavation during accelerator shutdown
- NOvA beam turns on Feb. 2013
- FD finished in early 2014



Backup



Far Detector

- 14,000 18,000 tons
- Will detected oscillated beam
- Largest object ever built of plastic





Quality Control

- Light Yield
 - Use radioactive sources to verify sufficient scintillator light
- Chemistry
 - Verify correct chemical composition.

- Clarity (15 m long far detector cells)
 - Use a "tintometer"
 - Maintaining cleanliness critical at every stage!




This is what we found when we looked inside of one of the fluor blending totes for the NDOS. The green substance was not identified (my guess was Mountain Dew). It was thoroughly cleaned by the blending company before any scintillator components were added.




Neutrino Interactions

- Like the wind, you can't see neutrinos, but you can see their effects.
- Simulated events at right









Filling






- NDOS is filled with high-quality scintillator
- Pumping and piping systems being developed for Far Detector
- 6 tankers per week to Far Detector planned
- ~3,000,000 gallons



The NuMI Beam

 Small Cross section ⇒ we need large number of neutrinos ⇒ we need an intense beam





Our Scintillator Recipe

Liquid Scintillator

- 94.91% food grade mineral oil
- 4.98% pseudocumene (scintillant)
- 0.110% parts PPO (powder, wave shifter)
- 0.00153% bis-MSB (powder, wave shifter)
- 0.0010% Stadis-425 (anti-static)
- 0.0010% Vitamin E (antioxidant)
- 1. Mix PPO, bis-MSB, Stadis-425, and Vitamin E into pseudocumene to produce fluor blend.
- 2. Mix fluor blend into mineral oil to produce NOvA liquid scintillator

Preserving and Redistributing APDs

- Running remaining APDs without cooling to preserve them
- Have begun be rearranging surviving APDs on the NDOS to collect highest quality data possible.

