



XRAY IRRADIATION PROCESS SIMULATION

WITH *RAYXPERT*®



Ludovic EYCHENNE
Antoine GHILARDI
22nd of September





is a software developed by **TRAD Tests & Radiations** since 2012 that associates a **3D modeling** tool to a **Monte Carlo** calculation method to perform radiation simulation and dose rate calculation for the **Industry**, the **Nuclear & Medical fields**

Electron & Positron

Gamma & Xray

Neutron

Industrial process

- ❖ OQ & PQ
 - ❖ Product and Packaging design
 - ❖ Source optimisation
 - ❖ Transfer from Gamma/ETO to Xray/Ebeam
-
- ❖ Non destructive inspection
 - ❖ Mining extraction & purification

Total : Kerma eau
(Gy/h)

2.54E+04
1.514E+04
9844
6398
4158
2703
1757
1142
742.2
482.4
312.2

Radioprotection


- ❖ Xray and Ebeam equipment design
 - ❖ Bunker design – new built and evolution
-
- ❖ Transport study
 - ❖ Building & Storage room design
 - ❖ Dismantling & Waste Management

Photon : DeD H*10
(Sv/h)

100 mSv / h
< 100 mSv / h
< 2 mSv / h
< 25 µSv / h
< 7.5 µSv / h


CONTEXT OF THE STUDY

How can Monte Carlo codes be used to optimize the number and location of dosimeters during an industrial medical irradiation process?



CONTEXT OF THE STUDY

Dosimetry optimization of an Xray irradiation process on a Medical Device



3D MODELING

Use **CAD import** associated to modeling tools to define 3D model

SOURCE DEFINITION

Define the beam shape, trajectory and spectrum

3D MAPPING

Perform the irradiation process on the products and calculate a 3D mapping to locate the **minimum** and **maximum** dose areas

VIRTUAL DOSIMETERS

Perform the irradiation process with dosimeters located on the specified areas

ANALYSIS & OPTIMIZATION

Dose distribution analysis regarding to different configuration of the product to find the most efficient way to proceed

3D MODELING

SOURCE DEFINITION

3D MAPPING


VIRTUAL DOSIMETERS

**ANALYSIS &
OPTIMIZATION**


3D MODELING AND CAD IMPORT THE PRODUCTS



3D MODELING




Product




Drain bag
(CAD file)

Products on a
cardboard box



Products on a carrier



3D MODELING

SOURCE DEFINITION

3D MAPPING

VIRTUAL DOSIMETERS

**ANALYSIS &
OPTIMIZATION**

BEAM SETUP





SOURCE DEFINITION



Settings :

- Double sided irradiation
- 2 × 7 MeV Ebeam
- 2 × Ta conversion target



Simplified
converter


SOURCE DEFINITION

Physics involved

Simulate statistically the interactions between radiations and matter


Photons

Photoelectric effect




Predominance
 $E < 50 \text{ keV}$

Compton diffusion



Predominance
 $0.05 \text{ MeV} < E < 20 \text{ MeV}$

Pair production



Predominance
 $E > 20 \text{ MeV}$

Secondary electron production → Dose deposition

3D MODELING

SOURCE DEFINITION

3D MAPPING

VIRTUAL DOSIMETERS

ANALYSIS &
OPTIMIZATION


3D MAPPING INSIDE THE PRODUCTS






CALCULATION OUTPUT

3D mapping

- Kerma water calculated
- Results in Gy/h
- Virtual mapping in all cardboard boxes
- **22 680** voxels in total



RESULTS WITH A 3D MAPPING



3D MODELING

SOURCE DEFINITION

3D MAPPING

VIRTUAL DOSIMETERS

ANALYSIS &
OPTIMIZATION


VIRTUAL DOSE MAPPING



CALCULATION OUTPUT

Detectors

- Absorbed dose calculated
- Results in Gy/h
- Full of water with
$$\rho = 1.0 \text{ g/cm}^3$$
- Dimensions :
 - $2 \text{ cm} \times 0.8 \text{ cm} \times 125 \text{ }\mu\text{m}$
 - *similar to a CTA film*



RESULTS IN THE DETECTORS

Detectors	Absorbed dose in water (kGy/h)*		Kerma water (kGy/h)*	
	Value	Standard deviation	Value	Standard deviation
Maximum location	22.2	6.4%	25.2	0.5%
Minimum location	19.2	6.8%	20.2	0.5%

- Quantities available for the dose calculation
- Dosimeters can give both quantities (alanine, CTA etc.)
- Have to choose the quantity in your interest

*calculations for 1σ

3D MODELING

SOURCE DEFINITION


3D MAPPING

VIRTUAL DOSIMETERS


ANALYSIS &
OPTIMIZATION

DIFFERENT CONFIGURATION






Simulation **adaptability** and **responsiveness** allow easily to test different configuration of the product




Simulation **adaptability** and **responsiveness** allow easily to test different configuration of the product

Vertical



Horizontal




CONCLUSION

As a complementary tool to dosimetry and OQ/PQ dose mappings, simulation results help to optimize the dosimetry and the process

- ✓ precise localisation of minimum and maximum dose areas
- ✓ precise localisation of dosimeters, reduce dosimeters number
- ✓ irradiation duration : dose rate information
- ✓ test different configurations
- ✓ optimise the process
- ✓ reduce human errors

And at the end, Monte Carlo simulation helps to

- ✓ **Reduce cost of dosimetry**
- ✓ **Increase confidence in dose mapping**
- ✓ **Increase your efficiency (Quality/Qualification time)**



WHAT DO THE STANDARD SAY ?

TODAY

?



DOSE MAPPING

SIMULATION

For Medical device sterilization by radiation processing

11137-3:2017

→ Calculation results should be verified with dose measurements


- ✓ **The combination of Monte Carlo simulation and dose mapping can significantly reduce the number of dose mappings required**
- ✓ Can be used to ensure that you use enough dosimeters placed on the minimum and maximum dose zones
- ✓ Can be used to choose the right type of dosimeter
- ✓ Can be used for interpolating measured results to determine the dose distribution for non-homogeneous products
- ✓ Can confirm that dose specifications can be met
- ✓ Can help you to determine the optimum irradiation radiation scenario

TRAD Tests & Radiations



Since 1994, we have been helping our customers with their projects involving radiation issues. From Space to Earth, with simulation & radiation processing


SOFTWARES EDITORS & ENGINEERING



RADIATION RESISTANCE TESTS



RAD HARD ELECTRICAL COMPONENT



For more information :

rayxpert.com
trad.fr

r2cots.com
fastrad.net



**INDUSTRIAL
SOLUTIONS**





Damien PRIEELS – Product Manager (Research)

IBA & TRAD decided to enter into a long-term partnership



INDUSTRIAL
SOLUTIONS



- ✓ Active in radiation processing market & shared vision
- ✓ Strong complementarities
- ✓ Potential for synergies



NUCLEAR ENGINEERING



INDUSTRIAL IRRADIATOR



MEDICAL



Sept. 21st, 2021



- Marketing
- Sales
- R&D




Specific module of RayXpert dedicated to radiation processing

We believe Monte Carlo will help significantly OQ & PQ



INDUSTRIAL
SOLUTIONS



We are looking for candidate(s) to participate to a MC study

Objective & Content

Demonstrate MC simulations help OQ & PQ
and therefore support the transition from EO & gamma to EB & XR

- ☐ Selection of appropriate center(s) & product(s)
- ☐ Optimization of Qualification process AND/OR product packaging + MC study with RayXpert®
- ☐ Dose mapping
- ☐ Evaluation of benefits for the stakeholder



www.iba-industrial.com

INDUSTRIAL
SOLUTIONS



www.trad.fr



Aerial

www.aerial-crt.com



Application & Benefits

You are interested
&
You have process/product(s) you want to
qualify

Apply @

www.iba-industrial.com/form/call-applications

(places are limited)

- ☐ Access to RayXpert
- ☐ Qualification of your process or product(s)
- ☐ Support from TRAD, IBA & Aerial

Today

October 15th

November 15th

Mid 2022

Call for candidates

Selection (3 max)

6 months study

Thank you for your attention

Application form to participate to the POC



www.iba-industrial.com/form/call-applications

Contact: damien.prieels@iba-group.com
antoine.ghilardi@trad.fr

