

Fiber-to-SiPM Coupling Studies



by **Sebastian Ritter** – 26.10.22

sebastian.ritter@uni-mainz.de

on behalf of Volker Büscher, Karl-Heinz Geib, Asma Hadeif, Lukas Koch,
Antoine Laudrain, Lucia Masetti, Marisol Robles Manzano, Paula Nehm,
Steffen Schönfelder, Liam O'Sullivan, Anna Rosmanitz, Christian Schmitt,
Patricia Theobald, Alfons Weber, Quirin Weitzel


JOHANNES GUTENBERG
UNIVERSITÄT MAINZ



OUTLINE

- Motivation
- Concept
- Prototype
- Measurements
- Results

SCINTILLATOR STRIP READOUT








- Scintillator strips with wavelength shifting fiber for better signal propagation
- Readout of fiber with photo sensor at the end of the strip (usually SiPM)

TWO MAIN CHALLENGES

- Usually, fiber directly attached to SiPM
 - Glue/gel
 - Mechanical structures
- Precise **attachment** and **alignment** structures necessary
- Fiber and SiPM **geometries don't match**


STATE OF THE ART FIBER READOUT

Lots of individual parts to ensure direct contact and alignment of fiber and SiPM



GEOMETRY MISMATCH

- Fiber-to-SiPM distance is key parameter
 - **Too close: (case 1)**
quicker saturation, loss in dynamic range
 - **Too far: (case 2)**
light not hitting active area is lost
- Relative **alignment in sub-mm range necessary**



- Examples:
 - T2K: 1 mm fiber + 1.3x1.3 mm² SiPM - only 46% coverage
 - Mu2e: 1.4 mm fiber + 2x2 mm² SiPM - only 38% coverage


CONCEPT

■ **Wanted:**

- Low space consumption
- Plug-and-play design / minimal number of parts
- Maximum coverage of SiPM




■ **Concept:**

- Insert **reflective cavity** between fiber and SiPM
- Illuminate SiPM **homogenously**
- **Optimized distance** for different fiber and SiPM pairs
- **Minimize light loss** in coupling
- **Utilization of full dynamic range**





PROTOTYPE

- 3D-printed piece with bayonet mount
- Inside coated with highly reflective film (3M DF2000MA)
- Fiber-to-SiPM distance variable to determine optimum
- Air gap between cavity and SiPM minimized
- Cavity footprint matching active SiPM area





MANUFACTURING STUDIES

- Manual insertion of foil only suitable for prototyping
- Exploring aluminum sputtering as coating technique
 - Application of single atoms on surface with plasma
 - Resulting reflectivity very sensitive to surface finish
- Poor surface quality of 3D print resulted in dull coating
 - Different manufacturing techniques might yield better, faster and cheaper results (injection molding/different 3D printing technique)
 - Other coating methods to be explored
- **Easier manufacturing crucial for success**




SETUP

- Scintillator illuminated by pulsed UV-LED
- 1.0/1.5 mm Y-11 WLS
- Hamamatsu S13660 SiPM
 - 3x3mm active area
 - 25/50 μm pixels
- Precisely adjustable (<0.25 mm) distance (z) between fiber and SiPM




RESULTS FOR S13660-3025 SIPM + 1 MM FIBER



RESULTS FOR S13660-3025 SIPM + 1 MM FIBER

Low LY curves:


- Up to about 150 p.e.
- First data point has the highest signal (*not saturated*)
- Plateau at the start
- Initial drop between 0.75- and 2-mm distance
- Steady decline at higher distances



RESULTS FOR S13660-3025 SIPM + 1 MM FIBER

Medium LY curves:


- Around 150 to 3000 p.e.
- First data point not the highest anymore (*saturation*)
- Plateau at the start
- Initial rise to the maximum between 0.75- and 1.5-mm distance (*illumination of larger SiPM area + desaturation*)
- Drop from maximum to around 2-mm distance
- Steady decline at higher distances



RESULTS FOR S13660-3025 SIPM + 1 MM FIBER


High LY curves:

- Starting at 3000 p.e.
- First data point is lowest data point (*saturation*)
- Plateau at the start
- Rise between 0.75 and 2 mm (*illumination of larger SiPM area*)
- Plateau, because light level too high for SiPM to desaturate




SIMULATION VS. REALITY

- Simplified geometrical simulation
- Simulated signal shape very similar to real data
- Results suggest signal loss caused by loss in protective epoxy layer
- Slope of tail determined by reflectivity of coating




Comparison measurement vs. simulation



PHOTON DETECTION RATIO


- Ratio of detected photo electrons vs. normalized number of photons leaving the fiber
- Maximum is limited by the PDE (0.25) of the SiPM
- The detection ratio gets smaller at higher photon numbers (*saturation*)

Fiber-to-SiPM distance of zero only the best at low intensities



COMPARISON OF RESULTS

S13660-3025 + 1.0 mm fiber





Less pixels

- saturates faster
- better at low LY




Bigger fiber

- higher LY (40-50%)
- less desaturation
- bigger plateau at x=0




RELATIVE RESOLUTION

- Relative resolution $\frac{\Delta N_{ref}}{N_{ref}}$
based on the shot noise of a single hit (z-scale in %)
- Distance for optimal resolution highly dependent on light level (N_{ref})
- Resolution gets better for $z > 0$ starting from 1000 p.e.




COMPARISON OF RESULTS

S13660-3050 + 1.0 mm fiber




- Lower pixel number
- Saturation/improvement start at lower LY
- Optimal resolution at around 2k p.e.

S13660-3025 + 1.0 mm fiber



- Saturation starting at 6-8k p.e.
- Optimal resolution at around 10k p.e.
- Improvement from coupling from about 1000 p.e.

S13660-3025 + 1.5 mm fiber



- Similar to 1.0 mm fiber
- Better coverage with bigger fiber
 - Better resolution
 - Improvement only at higher LY

DISCUSSION

- Proof of concept and advanced studies completed for prototype
- Further R&D in manufacturing necessary
- Possibility of extensive cost saving by using SiPMs more efficiently instead of using more expensive models

- Resolution increase at high LY
- **Easy handling and mounting for any application**

Questions?

Contact: sebastian.ritter@uni-mainz.de