


QC/QA Plans for Calibration/Monitoring System

Zelimir Djurcic, David Martinez,
Steve Magill, Aleena Rafique, Patrick DeLurgio, Mike Oberling, Todd Hyden,
Kole Pickner, Ian Helgeson, Diana Leon, Jairo Rodriguez

Nov 15 2022






Schematic of the UV light calibration/monitoring system



Preliminary Quality Control Optical Fibers

Some of the recorded information in lab tests that could be used in ProtoDUNE Run 2. Database:

- 1) Date manufactured
- 2) Fiber Type:
 - Default (ProtoDUNE RUN 1)
 - Alternative (Tefzel)
- 3) Fiber length (before and after assembly SMA connector)
- 4) Polishing Quality
- 5) Transparency Test



Preliminary Quality Control on PEEK 3D printed diffusers

- Some of the recorded information in lab tests could be used in ProtoDUNE Run 2




Database:

- 1) Date 3D printed
- 2) Dimensions of diffuser
- 3) Sharp edges removal
- 4) SMA Fit
- 5) Mass
- 6) Light test

New single hole design of diffuser



Light Test – Diffuser



Quality Control Optical Feedthrough

- Optical Feedthrough:


-The following QC information should be saved in database:

ID, ch#, PH0, PH1, pulse width used, led bias applied, success (yes/no), date tested

Each feedthrough has five channels (1-5)

- PH0 is the pulse height (light yield) before optical feedthrough.

- PH1 is the pulse height (light yield) after optical feedthrough.



Quality Control Calibration Module with Light Sources

- Calibration Module with the light source:
 - The following QC information should be saved in database:
ID, ch#, PH0, PH1, pulse width used, led bias applied, success (yes/no), date tested

Each calibration module has 12 channels (1-12).

- PH0 is the pulse height (light yield) from the light source
- PH1 is the optional test of the light yield in additional configuration
(will keep this as a placeholder)

