



Measurement of Rayleigh Scattering in Liquid Argon at Vacuum Ultraviolet Wavelengths

Larry Zhao

SULI Oral Presentation

6 December 2023

- a. This manuscript has been authored by Fermi Research Alliance, LLC under Contract No. DE-AC02-07CH11359 with the U.S. Department of Energy, Office of Science, Office of High Energy Physics.
- b. This work was supported in part by the U.S. Department of Energy, Office of Science, Office of Workforce Development for Teachers and Scientists (WDTS) under the Science Undergraduate Laboratory Internships Program (SULI).

Introduction

DUNE Experiment

Physics Objectives

- Long Baseline Neutrino Oscillation Measurements
 - Answer neutrino questions
 - Neutrino Mass Order
 - Presence of Leptonic CP Violation
 - Possible Unitary Neutrino Mixing Matrix
- Observe Galactic Supernovae Neutrinos
 - Rare opportunity to study astroparticle physics in extreme environments
 - Measurable impact of neutrino-neutrino interactions?
- Potentially discover nucleon decay
 - Major potential discovery and inform Beyond the Standard Model (BSM) Physics)




Introduction



DUNE

Design

- Long Baseline Neutrino Facility (LBNF)
 - Located at Fermilab
 - Generates high-intensity neutrino beam
- Near Detector (ND)
 - Located at Fermilab
 - Measures initial neutrino beam composition produced by LBNF
- Far Detector
 - Located at Sanford Underground Research Facility, South Dakota
 - 4 time projection chambers (TPCs), 40 ktons of liquid argon total
 - Measures neutrino beam spectrum after oscillations
 - Detects potential supernova neutrinos
 - Detects potential nucleon decays






Far Detector Module
Image Credits: DUNE

Introduction

Top Right: LBNF Facility (Credits: DUNE)

Bottom Left: ProtoDUNE Diagram (Credits: Alex Himmel)

Bottom Right: ProtoDUNE Interior (Credits: DUNE)



Introduction



DUNE Detector Operation

- LArTPCs - charged particles ionize argon atoms and produce scintillation light
- Ionization Charge
 - ~40% of deposited energy
 - Electric field → charge drifts toward anode, measured by wires or planes
 - Records charge signal in two dimensions, third dimension measured from relative arrival time
- Scintillation Light
 - ~60% of deposited energy
 - Characteristic spectrum emitted after excitation by ionizing radiation (argon peak at 128 nm)
 - Detected by photon sensors (e.g. photomultiplier tube (PMT) or silicon photomultiplier (SiPM))
 - Determines the absolute time (arrival difference between scintillation light and charge)
 - Compare scintillation light time (ns scintillation production+speed of light propagation) to drift charge time (<~6000 μ s from emission to detection) to calculate third dimension
- Reconstruction of event position needed to define fiducial volumes for exclusion of background and correction of charge signal attenuation

Motivation



SULI Project Objectives

- Potential for photon detector system to advance DUNE physics objectives by enabling a second calorimetric measurement of event energy
 - Second energy measurement improves analysis outcomes
 - Improves overall energy resolution since light and charge energy measurement resolution have different limitations
 - Provides in-situ cross-comparison of the TPC energy measurement, reducing systematic uncertainty of the energy measurement
- Scintillation light role currently limited by ability to reconstruct photon signals due to Rayleigh scattering
- Measuring the Rayleigh scattering length of scintillation wavelengths in LAr is first step to developing additional photon system analysis capabilities
 - Previous measurements and calculations claim wide ranges of values from 55 cm to >130 cm for the Rayleigh scattering length of 128 nm light in liquid argon


Measurement

TallBo Cryostat Setup

- Deuterium Lamp: produces UV light spectrum
- Monochromator: selects single UV wavelengths
- Collimator: reduces beam dispersion
- TallBo Cryostat: designed for liquid argon optics tests
- VUV SiPMs: detects photons
- Reflection Suppressor: absorbs incident light, prevents reflections

Measurement Theory

- Measure photon rate of SiPM directly below light source at multiple liquid argon depths
- Lower liquid argon volume results in less scattering and a greater photon rate
- Curve fitting the photon rate versus liquid argon depth gives the Rayleigh scattering length



TallBo Cryostat
(diagram by Alex Himmel)

Measurement


Run Procedure

- Fill cryostat to maximum liquid argon level
- Measure background rate and lamp on rate of wavelengths from 124 to 180 nm
 - SiPM response is temperature dependent → only consider submerged SiPMs
- Lower level and repeat measurement

Analysis Procedures

- Check 1 SiPM trigger event waveform corresponds to 1 photon
- Confirm the shallowest submerged SiPM has greater signal rate than deepest submerged SiPMs
- Plot bottom SiPM trigger rate versus depth
- Curve fit rate vs depth plot to exponential decay function for Rayleigh scattering length l



$$rate = ae^{-z/l} + b$$



TallBo Cryostat

SULI Summer Summary



- Setup experiment equipment, develop hardware operation procedures
 - Grounding issues with Arduino (timing control) and monochromator motor power supply
 - Issues with performance of some SiPMs
 - Data collection, transmission rate limitations
- Conduct analysis to understand SiPM signal waveforms
- Create procedures for measurement run 1
- Run 1:
 - Results unexpected
 - Turn over effect when comparing background subtracted rate versus depth at different wavelengths
 - Background division plot is better fit to expected exponential behavior than background subtraction
 - Future tests focus on understanding sources of behavior and solutions to remove additional effects



Bottom SiPM Rate vs Depth
(Background Subtraction)

SiPM Waveforms


- SiPM Waveform Signals
 - Data transfer rate is limited, so only save SSP calculated data (no raw waveform values)
 - Plots of energy spectrum (waveform signal peak integral) are consistent with combination of
 - Single photon signals
 - SiPM crosstalk between pixels (single photon appears to be two photons)
 - background contribution from radiation, SiPM dark count
- Background
 - Argon-39 radioactive decay scintillation signals
 - Contributes to change in background rate at different liquid depths
 - Eliminated through background subtraction
 - Cosmic Ray Scintillation
 - SiPM Dark Count



Peak Sum (Initial Peak),
Integrated Sum (Peak+Tail)

Liquid Argon Purity Diagnostics

- Vacuum Ultraviolet light is extremely susceptible to absorption from contaminants (Water, N₂, O₂, etc.)
 - Constant contaminant level is important to ensure stable light flux entering liquid argon
 - Test by measuring liquid argon triplet lifetime
 - Take high peak waveform data of background radiation
 - Calculate average value of each point in waveform, curve fit to find triplet lifetime
 - Measured lifetime of 1.4 microseconds, consistent with known value of 1.3 microseconds



Triplet Lifetime Plot, Curve Fit


Simulation Comparison

Geant4 Simulations on DUNE computers


- Create cryostat, detector geometry
- Add photons using particle gun function
- Check detector geometry and photon beam tracks using OpenGL visualization
- Plot shows photon number is greater on shallower submerged side SiPMs compared to deeper submerged side SiPMs
 - Light flux greatest at light beam point of entry at liquid surface
 - As light travels through liquid argon, more light is attenuated and the beam intensity decreases
 - Less scattered photons at deeper liquid argon depths

Measurement

- Qualitatively agrees with simulation
 - SiPMs closer to liquid surface observe more photons




Geant4 Simulation Detected Photons per SiPM (log scale)



Run 3 Measured Rate vs SiPM Height

Run 2


- Understand major issue - light intensity entering cryostat is not constant
 - Deuterium lamp requires warm-up (~30 min) to stabilize after powered on
 - The gaseous argon purge procedure caused varying levels of contaminants over time inside the monochromator
 - Lowering contaminant level lowers VUV wavelength light absorption
 - Resulted in lamp intensity increasing over 8+ hours as contaminants are constantly removed
 - Curve fitting and subtracting warm up effect is inconsistent (depends on purge rate) + results in greater error
- Solution: change setup to allow constant gaseous argon purge (previously required turn off overnight for safety), and leave lamp on
 - Resulted in constant lamp intensity versus time




SiPM Signal Rate vs Time
(Background Subtraction)

Run 3

- Analysis results are significantly improved due to lamp intensity stability, but still factors to be solved
- Incident due to pressure rupture disk failure overnight during run
 - No pressure control, forced cryostat to be opened to atmosphere
 - Pressure levels different from before incident, leading to possibly unusable data for lower LAr depths
 - Further investigation found impact of incident on data is likely small
 - Plot still displays turnover effect
 - Liquid argon temperature gradient → inconsistent SiPM gain
- Longer wavelengths follows positive (incorrect) slope
 - Scattering length may be too long to measure for setup, but that implies 0 slope and does not explain a positive correlation
 - Possible additional rate dependence on liquid level to understand and correct



128 nm Bottom SiPM Signal Rate vs Time



Bottom SiPM Signal Rate vs Time

Conclusions

- Waveform Measurement
 - Single trigger consistent with single photon detection
- Triplet Lifetime Measurement
 - Triplet lifetime consistent with high purity liquid argon
- Run 1
 - Initial measurement, understand behavior of unexpected effects
- Run 2
 - Implement new procedures to stabilize incident light intensity
- Run 3
 - Preliminary Rayleigh scattering length of 125.7 ± 22.37 cm for 128 nm wavelength

Future Work

- Exhaust other data analysis possibilities for data set
- Correct for SiPM gain difference between SiPM Channels

Acknowledgements

Advisors:

Dr. Alex Himmel (Scientist)

Dr. Wei Mu (Research Associate)

Noble Liquid Test Facility Staff

- Dr. Flor Blaszczyk (Applications Physicist)
- Dr. Sergey Koshelev (Senior Engineer)
- Dr. Alex Kish (Applications Physicist)

