

FBK IV analysis* @ Ferrara

*tested by FBK

M. Andreotti, R. Calabrese, D. Casazza, A. Cotta Ramusino, S. Chiozzi, R. D'amico, M. Fiorini, T. Giammari, M. Guarise, E. Luppi, I. Neri, L. Pierini, L. Tomassetti, in collaboration with the Bologna group

DUNE photo-sensor meeting

22/10/2024

Content

- General info
- Differences with CACTUS typical data
- Results
- Changes in the algorithm
- Additional results

General info

Samples

- 100 SiPM strips
- FBK model (HD pre-production)

Aim

- Compare the IV characterization methods
 - CACTUS : relative derivative $\rightarrow \frac{d}{dV} (\ln(I))$
 - Vendor : 2nd logarithmic derivative method $\rightarrow \frac{d^2}{dV^2} (\ln(I))$


Differences with our typical data

Disclaimer: The CACTUS analysis algorithm is somehow optimized for HPK strips, due to a higher population of measurements


Differences with CACTUS standard measurements

- Higher V_{step} : 50 mV vs [10 – 20] mV
- Lower noise : probably due to different instrumentation

Results – V_{BD} distribution



Results – mean V_{BD} per strip



Differences with our typical data

Disclaimer: The CACTUS analysis algorithm is somehow optimized for HPK strips, due to a higher population of measurements

Differences with CACTUS standard measurements

- Higher V_{step} : 50 mV vs [10 – 20] mV
- Lower noise : probably due to different instrumentation

Differences with our typical data

Disclaimer: The CACTUS analysis algorithm is somehow optimized for HPK strips, due to a higher population of measurements

Differences with CACTUS standard measurements


- Higher V_{step} : 50 mV vs [10 – 20] mV
- Lower noise : probably due to different instrumentation

The range of the parabolic fit is not optimized


Changes in the algorithm

Raise N_{FIT}^* ($5 \rightarrow 8$) in favor of V_{BD} spread

Tray 55492, strip S0001_L, SiPM 1





Tray 55492, strip S0001_L, SiPM 1




* Minimum number of points for the parabolic fit around the first guess of V_{BD}

Results - N_{FIT} - V_{BD} distribution



- ~ same mean value ($\Delta = 2$ mV)
- Smaller spread

Results - N_{FIT} - V_{BD} distribution



Conclusions

- Received IV characterizations data from FBK
 - 100 strips (for HD pre-production)
- Analysis with standard CACTUS algorithm
- Differences with our data → tune the algorithm
 - Optimization of fit range
 - Impact on the results

BACKUP

Reverse IV analysis methods

