

CERN High Energy Accelerator Mixed Field (CHARM) Facility

R. Froeschl, M. Brugger, S. Roesler (CERN)

April 28, 2014

Description and Requirements

Prompt Radiation


Residual Radiation

Air Activation and Requirements for Dynamic Confinement

CERN Shielding Benchmark Facility

Motivation

- Objective of R2E project (Radiation2Electronics):
 ≤ 0.5 dumps per fb^{-1}
- Radiation test for electronic equipment (power converters, electronic devices)
- CHARM project to provide test locations with well understood, typical mixed radiation fields
(in addition to existing facilities CNGS, CERF, H4IRRAD, IRRAD)
- Space in CERN–PS East Experimental Hall available due to decommissioning of DIRAC experiment
- Downstream of proton irradiation facility



Motivation

- Interest/importance of testing in mixed fields
 - allows testing in real representative conditions, thus not requiring multiple tests
 - enables testing full systems (up to 1mx1mx2m)
 - field/intensity can be adopted over large ranges
- Spectrum and impact on electronics
 - high-energy tail of spectrum (for several applications) can be dominant in case of destructive failures (e.g, latch-up)
 - thermal neutrons also play a role
- High number of representative fields
 - high-energy accelerators/experiments
 - aviation and high-altitude
 - space (lower orbits)
 - ground applications (e.g, radiation impact on large distributed systems)

Motivation

- New installation conceived as real facility
 - Large number of cables and services pre-installed
 - Preparation and dry-run area (same layout)
 - Technical control room
 - Optimized for Radiation Protection using an integrated, iterative design approach
- Detailed monitoring
 - Available for all tests
 - Detailed benchmark during commissioning


Location




Parameters

- Proton beam from CERN-PS with 24 GeV/c on target
 - 5E11 protons/pulse
 - Pulse length 350 ms
 - 2.2E10 protons/s nominal average beam intensity
 - 6.7E10 protons/s maximum average beam intensity
 - 3.3E17 protons/y nominal annual protons on target
 - 1E18 protons/y maximum annual protons on target
- Three targets
 - Copper
 - Aluminum
 - Aluminum with longitudinal slits to reduce effective density
 - Diameter 8 cm, length 50 cm
- Four movable shielding walls (20 cm) to allow adjustment of radiation fields
 - Two concrete walls
 - Two cast-iron walls


Integration – East Experimental Hall




Integration – CHARM





Integration – CHARM Target Zone




Integration – CHARM Target Zone




Integration – CHARM Target Alcove





Radiation Fields




Radiation Fields



Radiation Fields



Radiation Fields



Prompt Radiation – Design Goals

- **Area Classification:**

- $3 \mu\text{Sv}/\text{h}$ (control rooms) or $15 \mu\text{Sv}/\text{h}$ (low occupancy area) at 40 cm outside from shielding walls for maximum average beam intensity
- $2.5 \mu\text{Sv}/\text{h}$ outside of the hall for maximum average beam intensity
- Optimization of shielding passages (Access chicanes, ventilation ducts, cable ducts)

- **Sky-shine:** $1 \mu\text{Sv}/\text{y}$ to members of the public (reference group) for nominal/maximum annual protons on target


- **Monitoring:** Define locations for area monitors

- **Shielding design:**


- Re-use of existing concrete and iron blocks
- Space constraints due to already existing facilities/crane
- 2000 tons of iron, 4000 tons of concrete

- **Monte Carlo simulations:** performed with **FLUKA**


Prompt Radiation – Beam Line Level




Prompt Radiation – Beam Line Level (Area Classification)




40 cm above top shielding – 720cm above target



Sky-shine



Sky-shine – Annual effective dose to members of the public




Residual Radiation – Design Goals

- Reduce ambient residual radiation
 - Optimization
 - More efficient exploitation of facility
- Marble cover for some wall parts and ceiling
- Target alcove
 - Target moved to alcove during access
 - Movable marble shielding to close alcove
- Studies for different shielding configurations to optimize procedures
- $100 \mu\text{Sv/h}$ for the Patch Panel area (most frequent access)
- **Monte Carlo simulations:** performed with **FLUKA** and **DORIAN** code


Residual Radiation

- Sequence of movable shielding walls still to be decided in the next weeks
- Experience for shielding configuration management with the **DORIAN** code gained
- Plots shown
 - for **FeCoFeCo** shielding walls sequence
 - walls inside zone during irradiation, retracted after beam stop
 - target moved into alcove
 - alcove marble shielding closed


Residual DR after 200 days with 6.6E10 p/s and 1h of cool-down




Residual DR after 200 days with 6.6E10 p/s and 8h of cool-down




Residual DR after 200 days with 6.6E10 p/s and 1d of cool-down




Residual DR after 200 days with 6.6E10 p/s and 7d of cool-down




Residual DR after 200 days with 6.6E10 p/s and 30d of cool-down




Residual DR after 200 days with 6.6E10 p/s and 180d of cool-down



Residual DR after 200 days with 6.6E10 p/s in the patch panel area



Residual DR after 200 days with 6.6E10 p/s in the entry area



Air Activation – Methodology


- Design goals
 1. Committed effective dose due to inhalation:
 $\leq 1 \mu\text{Sv}$ for 1 hour access
 2. Effective dose to members of the public (reference group):
 $\leq 1 \mu\text{Sv}/y$
- Radionuclide concentrations and release
 - Track-length spectra scored in air volumes
 - Radionuclide production yields by weighting of spectra with dedicated air activation cross-sections
 - Dynamic confinement (controlled continuous release) to obtain release term
 - External effective dose to members of the public by dedicated Monte Carlo integration program (**EDARA**)

Air Activation

Confinement type	Committed effective dose due to inhalation without flush for 1 hour access μSv	Release to environment TBq/y	Effective dose to members of public $\mu\text{Sv}/\text{y}$
Static	60	-	-
Dynamic (1 volume/h)	1.9	2.4	0.10

- **Goal 1:** Dynamic confinement and flush before access
- **Goal 2:** Derived requirement on air tightness

Derived Requirement on Air Tightness




CERN Shielding Benchmark Facility – Motivation


- Lateral spectra after deep shielding penetration
 - 80 cm of iron shielding downstream of CSBF
 - 360 cm of shielding material in CSBF itself
 - Spectra can be adjusted by the modifying shielding material in CSBF
 - FLUKA simulations for detailed characterization to be performed
- Characterization of shielding material
- Detector calibration
- Detector inter-comparison
- Parasitic use of beam on CHARM target
- Minimize operational impact on CHARM facility

CERN Shielding Benchmark Facility – Sketch

Side View



Top View



CERN Shielding Benchmark Facility - Integration

- Two independent stacks
 - Centered above the CHARM target
 - Four meter downstream
- Each stack
 - Available depth 360 cm, 160 cm×80 cm area
 - 5 layers: 4×80 cm + 1×40 cm
 - Each layer is composed of 2 pieces, 80 cm×80 cm area
 - Cable feed-throughs
- Integration and Commissioning plans on-going
 - PhD student planned


Conclusions

- CHARM Facility for
 - testing complex electronic systems in
 - representative radiation environments
- Radiation Protection assessment approach
- CSBF for deep lateral shielding penetration studies
- CHARM will start to receive beam mid-July 2014


Backup

Backup


Radiation Fields




Radiation Fields





Cross-Sections for Al




Test Locations





Radiation Fields




Radiation Fields




Radiation Fields



Prompt Radiation – Beam Line Level




Prompt Radiation – Beam Line Level (Area Classification)




Monitoring

- Radiation Protection monitors
 - AMF/AGM for prompt radiation
 - IAM for residual radiation
 - VMS for monitoring the release to the environment
 - Mobile AMF/AGM during commissioning
- Radiation field monitoring
 - RadMon (active, TID, displacement damage, high energy hadron flux, thermal neutron flux)
 - Beam Loss Monitors (BLM)
 - Beam intensity and profile monitoring


RP Monitoring



Residual DR after 200 days with 6.6E10 p/s in the rack area



Residual DR after 200 days with 6.6E10 p/s at 1m from the target position



Inhalation dose / Effective dose (1 volume per hour)

Radionuclide	Production yield	Total activity	Committed effective dose due to inhalation without flush for 1 hour access	Release environment	Effective dose to members of public
					nucl./primary
H-3	9.31E-03	3.14E+03	5.15E-04	1.66E-05	6.73E-07
Be-7	2.04E-03	5.81E+04	1.07E-02	3.07E-04	4.27E-03
C-11	2.80E-03	9.89E+07	5.40E-01	5.22E-01	2.77E-02
C-14	1.03E+00	7.48E+02	1.74E-03	3.95E-06	2.30E-05
N-13	4.08E-03	1.73E+08	5.23E-01	9.14E-01	3.50E-02
O-14	2.00E-04	1.02E+07	3.73E-03	5.40E-02	1.24E-03
O-15	2.63E-03	1.32E+08	8.27E-02	6.96E-01	9.26E-03
O-19	4.55E-07	2.37E+04	3.29E-06	1.25E-04	5.78E-07
F-18	7.52E-06	1.09E+05	3.37E-02	5.74E-04	3.32E-04
Ne-23	9.65E-07	5.02E+04	—	2.65E-04	1.41E-07
Ne-24	2.28E-07	1.11E+04	—	5.86E-05	6.44E-07
Na-22	2.42E-06	3.87E+00	3.10E-05	2.04E-08	1.20E-04
Na-24	3.63E-06	8.44E+03	1.75E-02	4.45E-05	5.88E-04
Na-25	1.58E-06	8.12E+04	—	4.29E-04	1.20E-06
Mg-27	2.05E-06	8.78E+04	—	4.64E-04	3.73E-04
Mg-28	5.85E-07	9.87E+02	6.60E-03	5.21E-06	6.99E-05
Al-26	3.25E-06	1.89E-05	1.06E-09	9.97E-14	6.93E-09
Al-28	7.40E-06	3.69E+05	—	1.95E-03	1.43E-03
Al-29	3.58E-06	1.63E+05	—	8.58E-04	5.82E-05
Si-31	4.34E-06	4.77E+04	1.85E-02	2.52E-04	5.82E-05
Si-32	2.39E-06	2.21E-02	4.86E-06	1.17E-10	2.45E-08
P-30	2.26E-06	1.12E+05	—	5.92E-04	2.35E-05
P-32	2.55E-05	2.71E+03	3.14E-02	1.43E-05	4.97E-04
P-33	1.91E-05	1.14E+03	5.93E-03	6.03E-06	3.37E-05
P-35	2.05E-06	1.06E+05	—	5.59E-04	3.39E-04
S-35	2.37E-05	4.12E+02	1.81E-03	2.17E-06	1.08E-05
S-37	7.61E-06	3.57E+05	—	1.88E-03	1.76E-04
S-38	4.53E-06	4.64E+04	—	2.45E-04	4.60E-04
Cl-34	9.72E-07	2.89E+04	—	1.53E-04	0.00E+00
Cl-36	5.68E-05	7.85E-04	1.60E-08	4.14E-12	1.94E-08
Cl-38	4.14E-05	1.15E+06	2.02E-01	6.07E-03	2.15E-03
Cl-39	7.71E-05	1.74E+06	3.72E-01	9.16E-03	4.10E-03
Cl-40	9.31E-06	4.74E+05	—	2.50E-03	8.78E-05
Ar-37	7.51E-05	3.26E+03	—	1.72E-05	1.48E-12
Ar-39	2.85E-04	4.41E+00	—	2.33E-08	7.59E-12
Ar-41	2.18E-03	3.15E+07	—	1.67E-01	1.29E-02
K-38	6.74E-07	3.00E+04	—	1.58E-04	5.24E-05
K-40	2.36E-06	7.67E-09	9.20E-14	4.05E-17	4.25E-13
SUM			1.85		