

Alt GATK update



Hans Wenzel


January 9th 2014



U.S. DEPARTMENT OF
ENERGY

 **Fermilab**

Outline



Calorimeter and Tracker Simulation

- Plans/Status from last time
 - Sampling calorimeter from last time
- Motivation
- Development environment
- How to tell art what we are producing
- Extending the gdm1 schema (colors)
- Examples:
 - PbF2 Crystal
 - Dual read out crystal calorimeter
- Plans






Image © Adam McCauley


Plan from last time



- Clean up code and put into artg4/artg4example git repository (done)
- Implement scheme to store/retrieve/analyze the data (Hits) (show)
- Import all SD/Hits classes, Analysis from Cats. Make sure we can do detector R&D (show examples)
- Add Color
- Integrate numi beamline physics list (not yet)





Example tiled Pb/scintillator calorimeter from last time



No visual Attributes?
 4mm x 30cm x 30 cm Pb,
 1mm x 30cm x 30 cm Sz

Szintillator Pb Absorbers






Motivation: Modular system

build detector from predefined components

Currently implemented
 PhotonSD
 TrackerSD
 CalorimeterSD
 DRCalorimeterSD




PhotonSD
 produces ArtPhotonHits

TrackerSD
 produces ArtTrackerHits

DRCalorimeterSD
 produces ArtDRCalorimeterHits

StoppingCalorimeterSD
 Pro. ArtCalorimeterHit

Development environment



Idea: Start with a working example

development machine:

gm2gpvm01.fnal.gov

Software Versions:

GEANT4_VERSION=v4_9_5_p01

ROOT_VERSION=v5_34_01

art v1_02_04


artg4 v0_0_1

git repositories:

<https://cdcv.s.fnal.gov/redmine/projects/artg4/repository>


<https://cdcv.s.fnal.gov/redmine/projects/artg4example/repository/show?rev=develop>

Development environment



Setup not complete!


```
source /gm2/app/software/prod/g-2/setup
setup gm2 v201211_1 -q e2:debug
cd gm22
source localProducts_v201211_1_debug-e2/setup
cd build
source gm2d setup_for_development
export G4LEVELGAMMADATA=/gm2/app/software/prod/external/g4photon/v2_2/NULL/PhotonEvaporation2.2
export G4REALSURFACEDATA=/gm2/app/software/prod/external/g4surface/v1_0/NULL/RealSurface1.0/
```



Tell art what we are producing

Change calling sequence

```
175 // We need all of the services to run @produces@ on the data they will store. We do this
176 // by retrieving the holder services.
177 art::ServiceHandle<ActionHolderService> actionHolder;
178 art::ServiceHandle<DetectorHolderService> detectorHolder;
179 detectorHolder->initialize();
180 //hjm:
181 //detectorHolder -> callArtProduces(this);
182 // Build the detectors' logical volumes
183 detectorHolder -> constructAllLVs();
184 // And running @callArtProduces@ on each
185 actionHolder -> callArtProduces(this);
186 detectorHolder -> callArtProduces(this);
```





Tell art what we are producing

```

void artg4example::GDMLDetectorService::doCallArtProduces(art::EDProducer * producer) {
    // Tell Art what we produce, and label the entries
    std::vector<std::pair<std::string, std::string> >::const_iterator cii;
    for (cii = DetectorList.begin(); cii != DetectorList.end(); cii++) {
        if ((*cii).second == "DRCalorimeter") {
            std::string identifier = myName() + "-" + (*cii).first + "-" + (*cii).second;
            producer -> produces<myDRCaloArtHitDataCollection>(identifier);
        } else if ((*cii).second == "Calorimeter") {
            std::string identifier = myName() + "-" + (*cii).first + "-" + (*cii).second;
            producer -> produces<myCaloArtHitDataCollection>(identifier);
        } else if ((*cii).second == "PhotonDetector") {
            std::string identifier = myName() + "-" + (*cii).first + "-" + (*cii).second;
            producer -> produces<myPhotonArtHitDataCollection>(identifier);
        } else if ((*cii).second == "Tracker") {
            std::string identifier = myName() + "-" + (*cii).first + "-" + (*cii).second;
            producer -> produces<myTrackerArtHitDataCollection>(identifier);
        }
    }
}

```

Contents of the root file





Add some color to your life:

```

1 <?xml version="1.0" encoding="UTF-8" ?>
2 <gdm1_simple_extension xmlns:gdm1_simple_extension="http://www.example.org"
3     xmlns:xs="http://www.w3.org/2001/XMLSchema-instance"
4     xs:noNamespaceSchemaLocation="SimpleExtension.xsd">
5   <!--|
6     //
7     // PbF2 optical data from:
8     // http://www.crystran.co.uk/
9     // http://www.crystran.co.uk/lead-fluoride-pbf2.htm
10    // the data values where estimated using:
11    // Engauge Digitizer - Digitizing software
12    // http://digitizer.sourceforge.net/
13    // Note! the formula used to calculate the absorption length from the transmission
14    // is not correct (too pessimistic) since it doesn't account for
15    // fresnel reflection.
16    //
17 -->
18
19   <extension>
20     <color name="test_color" R="0.1" G="0.2" B="0.3" A="1.0" />
21     <color name="magenta" R="0.0" G="1.0" B="0.0" A="1.0" />
22     <color name="green" R="1.0" G="0.0" B="1.0" A="1.0" />
23   </extension>

```


Gdm1 extension + modified parser
 for colors overkill
 But good to know e.g. for
 Implementing Segmentation/
 readout geometry or Fields
 Extensions ignored by standard
 parser

```

<auxiliary auxtype="SensDet" auxvalue="DRCalorimeter"/>
<!-- color extension element -->
<colorref ref="green"/>
</volume>
<volume name="PhotonVolume">
  <materialref ref="Si" />
  <solidref ref="PhotonBox" />
  <auxiliary auxtype="SensDet" auxvalue="PhotonDetector"/>
  <colorref ref="magenta"/>
</volume>


```

Cerenkov light in PbF2 Crystal




PbF2: no scintillation,
Good Cerenkov radiator,
used for em calorimeters
(e.g. g-2)

100GeV μ^+



```
PhysicsListHolder: {}
PhysicsList: {
  PhysicsListName: "FTFP_BERT"
  DumpList: false
  enableCerenkov: true
  enableScintillation: false
  enableAbsorption: true
  enableRayleigh: false
  enableMieHG: false
  enableBoundary: true
  enableWLS: false
}
```



Result:

Bulk (DRCalorimeter):









Photo Sensor (PhotonDetector)





Sensor: Photon energies






Dual Read out Calorimeter


500 MeV Proton in dual readout PbF2 crystal calorimeter



Plans




- Packaging
 - Move to latest version for products that we depend on.
 - Own product artg4tk
 -
- Learn how to use GPS artify simple particle Gun
- Add e.g. Birks to calorimeters
- Try out grid ...
- Provide more examples.



backup

Motivation



- Fast prototyping → make working with geant4 easy without obstructing its functionality.
- Avoid specialized application, changes to the detector don't require compilation → modular system.
- Don't reinvent the wheel (artG4, nova, LArSoft have solutions so art and Geant4 play together), CaTS provides example of modular system. GDML is a language to describe geometries....
- Make use of the components of CaTS → allow calorimeter R&D and other detector R&D projects to migrate to the new system.
- Grid: does relocate able UPS make life easier?
- Easier packaging, installation?
- Develop art expertise
- make use of software developed for art?

artg4

One producer that handles Geant: ArtG4Main

To make it generic, ArtG4Main delegates lots of responsibilities to **SERVICES** that are ONLY used by ArtG4Main.

The configuration files says what Services to load


GDML_Detector_Service
(creates the World and SD's)

MyEventAction


SteppingAction

MyPhysicsList

ArtG4Main
Producer




GDML




- Gdml developed to completely describe geometries, matched to the corresponding geant 4 C++ classes.
- Supported by geant 4 collaboration.
- Easily extendable to include e.g. sensitive detectors (done), visualization attributes (available), segmentation (not done).
- Several browsers exist that allow to visualize (debug) the Geometry.
- Converters available to change into different formats.
- clear separation of detector description (gdml) and run time configuration
- Sensitive Detector:
 - Knows how to create Hits and how to add hitlist to the event.
 - Is attached to a logical volume
(as specified in gdml file)
- To retain provenance gdml file is stored in run record.
- But: no scheme for segmentation/readout geometry (needed?)


Example PbF2 Crystal



Cosmic ray Muon (red)
producing Cerenkov radiation
in PbF2 Crystal. Photons are
read out at the narrow end of
the Crystal



Components



Detector Description:

GDML_Detector_service used to build G4 geometry and SD. Xml based gdml input file, with extensions for SD's and visual attributes (e.g. crystalcal.gdml) (Geometry, Materials, optical properties, sensitive detector), we provide working examples, no recompilation necessary. Added mechanism to add gdml file to the run record to retain provenance.

Persistency

Provided by art, uses Root reflexion (gccxml) to automatically, create dictionaries for all classes we want to write out (e.g. Hits)

Input modules:

GPS, Particle Gun, HEPMC (Pythia)

Physics Lists:

choice of all Reference Physics Lists which can be extended to include optical physics processes (Cerenkov, Rayleigh, Scintillation etc.) → make more modular, add numi-beamline (Julia)

Sensitive Detectors and Hits:

TrackerSD, CalorimeterSD, DRCalorimeterSD (also registers Cerenkov photons), DRTSCalorimeterSD (DR+time slices), StoppingCalorimeterSD, PhotonSD: sensitive detector that registers optical photons.

User Actions:

Art Service: examples of user actions (EventAction, RunAction, StackingAction, SteppingAction...) will be provided


Code repository, Redmine project & Instructions:

Use artg4/artg4examples git repository/redmine project.

Histogram manager


Art analyzer, examples provided for various SD.

Acknowledgement



Thanks to:

Paul, Marc, Chris, Rob, Krzysztof, Daniel, Adam



Calorimeter and Tracker Simulation






Image © Adam McCauley

Technical




- Framework: Art → worked with it in the past
- Code Repository: Redmine and Git since this is used by ART and artg4 → requested to create the project (CaTS).
artg4:
<https://cdcvns.fnal.gov/redmine/projects/artg4>
- Detector description: options gdm1 e.g. used by nova/CaTS
extension of Geant4., fhicl: used by artg4, custom: used by mu2e
- release management: relocatable ups???
- build system: cmake (used by Geant 4, CaTS....)
- environment setup: custom shell script
- development machine: (something with art and artg4 installed)
gm2gpvm → got an account still waiting for instructions to set up the environment.
- Execution: for now use Geant 4 VO and (limited) grid resources to execute jobs

Technical (cont.)



- Display of results: use geant 4 web application and database hosted here at fermilab (just create a new category)
- Configuration of physics lists/ processes: → discuss with Robert, look how it's done in G4


ART based package to monitor physics relevant to intensity frontier physics experiments



[Hans Wenzel](#)

November 21st 2013

CaTS: Calorimeter and Tracker Simulation




CaTS is a flexible and extend-able framework (based on geant4 and ROOT) for the general simulation of calorimeter and tracking detectors.

In the following look at CaTS to:


- **identify the features that we want,**
- **features that should be replaced by services of Art,**
- **extensions ??**

Charge



- Extension of geant 4 validation effort but geared specifically towards the needs of the intensity frontier community.
- develop an ART based package for monitoring of all identified physics plots relevant to intensity frontier experiments at the model and physics list level.
- port elements of Julia's (stand alone) tests to ART and in addition integrate both EM and HAD plots into this package.
- explore the possibility to use the G4-ART interface.
- Develop tools to facilitate tests and customization of physics lists.
- The plots to monitor in this package will be associated with individual models (compared with thin target experiments aka first interaction) or physics lists, as well as with quantities to be validated with results from test beam and real experiments.
- For more complex validation, simplified geometry may be used or real configurations from the experiments could be imported to this ART application.

What does art do?




A “lite” forked version of the CMS framework

Supplies all expected framework services as well as links between data objects (Ptr's and Assn's)

Used by many Fermilab Intensity Frontier Experiments: (NOvA, g-2, Mu2e, MicroBoone, LBNE) and some others (e.g. DS50)

Written by SCD/CET department

Currently being adapted for multi-processing and DAQ



 Code you write  Code you use from the framework

What do you write?

You write modules that can access data and do things at certain times

Types of MODULES:

(All modules can read data from the event)

o Input source:

A source for data. E.g. a ROOT file or Empty for start of simulated data

o Producers:

Create new event data from scratch or by running algorithms on existing data

o Filters:

Like producers, but can stop running of downstream modules


o Analyzers:

Cannot save to event. For, e.g. diagnostics plots

o Output module:

Writes data to output file (ROOT). Can specify conditions and have many files

Input source



Begin job

Begin run

Begin subrun

Process event (produce, filter, analyze)

Process event (produce, filter, analyze)

Process event (produce, filter, analyze)

End subrun

End run


⋮

End job

All modules can make and write out ROOT histograms and Trees

Chain modules - but an important golden gule


Modules must only pass data to each other via the EVENT




Modules should not communicate with each other, except through the event.

Restriction is necessary to break chain, handle multiprocessor processing and for sanity.


There are RUN and SUBRUN buckets too



Art Glossary




Gdml file (1: schema and definitions)



```
?xml version="1.0" encoding="UTF-8" ?>  
<gdml xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"  
xsi:noNamespaceSchemaLocation=  
"http://service-spi.web.cern.ch/service-spi/app/releases/GDML/schema/gdml.xsd">
```

```
<define>  
  <variable name="i" value="0"/>  
  <variable name="j" value="0"/>  
  <variable name="k" value="0"/>  
  <constant name="numlay" value="2"/>  
  <constant name="numcol" value="2"/>  
  <constant name="numrow" value="2"/>  
  <constant name="scalex" value="300"/>  
  <constant name="scaley" value="300"/>  
  <constant name="scalez" value="5"/>  
  <constant name="absoffsetz" value="-0.5"/>  
  <constant name="szoffsetz" value="2.0"/>  
</define>
```

gdml file (2: materials)



<materials>


```
<element name="Oxygen" formula="O" Z="8."> <atom value="16.0"/> </element>
<element name="Nitrogen" formula="N" Z="7."> <atom value="14.01"/> </element>
<element name="Lead" formula="Pb" Z="82."> <atom value="207.20"/> </element>
<element name="Carbon" formula="C" Z="6."> <atom value="12.01" unit="g/mole"/> </element>
<element name="Hydrogen" formula="H" Z="1."> <atom value="1.01" unit="g/mole"/> </element>
```

```
<material name="Air">
  <D value="1.290" unit="mg/cm3"/>
  <fraction n="0.7" ref="Nitrogen"/>
  <fraction n="0.3" ref="Oxygen"/>
</material>
```

```
<material name="Scintillator">
  <D value="1.032" unit="g/cm3"/>
  <composite n="9" ref="Carbon"/>
  <composite n="10" ref="Hydrogen"/>
</material>
```

```
<material name="metalPb">
  <D value="11.340" unit="g/cm3"/>
  <composite n="1" ref="Lead"/>
</material>
</materials>
```

Gdml(3: solids, logical volumes)



<solids>


```
<box name="WorldBox" lunit="mm" x="5000" y="5000" z="5000"/>
```

```
<box name="CalorimeterCell" lunit="mm" x="300" y="300" z="4"/>
```

```
<box name="ScintillatorCell" lunit="mm" x="300" y="300" z="1"/>
```


</solids>

Gdml (4: placing the physical Volumes)




```
<structure>
  <volume name="CaloVol">
    <materialref ref="metalPb"/>
    <solidref ref="CalorimeterCell"/>
    <auxiliary auxtype="SensDet" auxvalue="Calorimeter"/>
  </volume>
  <volume name="ScintVol">
    <materialref ref="Scintillator"/>
    <solidref ref="ScintillatorCell"/>
    <auxiliary auxtype="SensDet" auxvalue="Calorimeter"/>
  </volume>
  <volume name="TOP">
    <materialref ref="Air"/>
    <solidref ref="WorldBox"/>
    <loop for="i" from="0" to="numrow" step="1">
      <loop for="j" from="0" to="numcol" step="1">
        <loop for="k" from="0" to="numlay" step="1">
          <physvol>
            <volumeref ref="CaloVol"/>
            <position name="posijk" x="scalex*(i-numrow/2)" y="scaley*(j-numcol/2)" z="absoffsetz+scalez*(k-numlay/2)"/>
          </physvol>
          <physvol>
            <volumeref ref="ScintVol"/>
            <position name="posijk2" x="scalex*(i-numrow/2)" y="scaley*(j-numcol/2)" z="szoffsetz+scalez*(k-numlay/2)"/>
          </physvol>
        </loop>
      </loop>
    </loop>
  </volume>
</structure>
```

Gdml (5: define the world)




```
<setup version="1.0" name="Default">  
  <world ref="TOP"/>  
</setup>
```

```
</gdml>
```




```
process_name:processA
source: {
  module_type: EmptyEvent
  maxEvents: 100
}
services: {
  message : {
    debugModules : ["*"]
    suppressInfo : []
    destinations : {
      LogToConsole : {
        type : "cout"
        threshold : "DEBUG"
        categories : {
          default : { limit : 50 }
        }
      }
    }
  }
}
```



TFileService :

```
{
  fileName      : "CheckHits.root"
}
user: {
  DetectorHolder: {}
  ActionHolder: {}
  RandomNumberGenerator: {}
  PhysicsListHolder: {}
  PhysicsList: {
    PhysicsListName: "FTFP_BERT"
    DumpList: false
    enableCerenkov: false
    enableScintillation: false
    enableAbsorption: false
    enableRayleigh: false
    enableMieHG: false
    enableBoundary: false
    enableWLS: false
  }
}
```



```
// Detector(s) for the simulation
```

```
GDMLDetector :
```

```
{
```

```
category: "world"
```

```
gdmlFileName_ : "tiledsamplingcal4mmpb1mmSz.gdml"
```

```
}
```

```
// Action(s) for the simulation
```

```
ClockAction: {}
```

```
ExampleGeneralAction: {  
  name: "exampleGeneral"
```


```
}
```

```
ExampleParticleGunAction: {  
  name: "exampleParticleGun"  
  use_HEP_event: true
```

```
}
```


```
}
```

```
}// end of services!!!
```




```
outputs: {
  out1: {
    module_type: RootOutput
    fileName: "exampleTestingout.root"
  }
}

physics: {
  producers: {
    artg4Main: {
      module_type: artg4Main
      enableVisualization: false
      macroPath: "../macros"
      visMacro: "vis.mac"
      //afterEvent: pause
    }
  }
  analyzers: {
    CheckHits: { module_type: CheckHits
                 hist_dir: "HistoDir"}
  }
}
```




```
path1: [ artg4Main ]  
stream1: [ out1, CheckHits ]
```

```
trigger_paths: [ path1 ]  
end_paths: [ stream1 ]  
}
```



How to store retrieve the data



Collect all Hit collection in a map:

```
std::map< std::string, vector<BaseArtHit*> >
```

String encodes:

- Logical Volume that the SD is attached so
- Class name of specific Hit class

```
ArtCalorimeterHit* DRHit = dynamic_cast<ArtCalorimeterHit*> (hits[ii]);
```