

Magnetic Field Engineering Update

CM36 IIT

Craig Macwaters 17/6/13






Contents...

- Tracker shielding can analysis
 Kiril Marinov (Daresbury)
- Tracker shielding can prototype
 Craig Macwaters
- Tracker individual shields км
- Integration engineering update Jason Tarrant (RAL)




The tracker cryo problem...


Field in AIR x-sect, looking upstream to Q9





Many sensitive items...










What about a big shielding can?

- Kiril Marinov at DL has worked on magnetic modelling and analysis and full details on modelling website
- CM looked at physical





Numerical results






Interferences





Step4 - Possible position of shielding cans - still many problems!





Position of south cryos


- Cones represent centre of can
- Radius approx 60cm
- Takes up a lot of thoroughfare




•WAVEGUIDE LENGTHS!!



Investigating waveguide reach



Old IC cryostat model



Spectrometer Solenoid model in MICE hall

	External waveguide (cm)	
Station ID	1st Set	2 nd Set
1	140	140
2	160	160
3	185	175
4	215	205
5	250	250




Henry trying to stretch the waveguides!






Half height model






116cm diameter can – relatively large




Possible new position of tracker racks : Ovals show a 7M reach from both cryo pairs



7M ovals allow a further 2.8M for vertical drops. Making 9.8M total for AFE backplane to VME crate for VLSB cables.

Baseline position for tracker racks (behind North Shield Wall)





Visualisation of rack behind NSW

- Checked OK by fire officer
- Very tight on VLSB cable lengths
- Need to detail and model
- Need to move RF Cage east gate





Tracker Shielding can summary

- Heavy, 4 x 7 Tonnes! Floor load?
- How easily can we move these big cans into and out from the beamline. Under south mezz would not be able to use the crane. Rails?
- South cryo positions completely foul Jason's compressor hose distribution
- Cost 4 x £20K?
- WAVEGUIDE lengths probably just too short. Could we angle the cryostats inwards?


Many issues so we decided to investigate local shielding...



Magnetic shield for Weiner PSU - KM



Concept: a shielding box with a pair of "chimneys"






Design considerations

- The "chimneys" serve several purposes...
 - Access for cabling
 - Bottom-to-top air convection
 - Possibility of additional fans or using compressed air
- The position of the air intake/outtake pair does not need to be in the centre. If needed, a second pair could be a added.
- There is a 50 mm gap between the PSU and the shield. This can be increased, but larger shielded volumes require thicker walls.
- Heat loss needs to be quantified as it will affect the design



Method




- The shield is placed between the poles of a window-frame magnet generating uniform field along Z of 30 mT
- The shield has been rotated around its three main axes and assessed in each configuration
- Weiner quote the PSU as able to tolerate up to 25 mT.


In all the subsequent plots the external field is always along the Z axis.



External field parallel to the air in/outtake axis



External field perpendicular to the air in/outtake axis



PSU Shield Summary

- Three orientations of the structure with respect to applied magnetic field have been considered.
- With a typical external field of >30 mT the field inside the shielded area is well below the target value of 20 mT.
- Better shielding can be achieved with thicker walls and longer chimneys. This design show satisfactory shielding with 5mm box.
- A prototype should be built and tested. This will help with eliminating a number of uncertainties, e.g. model validation, effect of welding on the magnetic properties of the steel, assessing power dissipation etc.
- Mechanically the box needs to be designed in such a way that opening and closing features do not affect the shielding performance.




Magnetic Shield for turbo pump and vacuum gauge

- KM

Leybold SL80 turbo pump.

This is the area that requires a shielding






Turbo shield design considerations


- The external field is of the order of 40 mT. The pump can tolerate 5 mT, regardless of field direction.
- The logical proposed solution is a 10 mm thick AISI 1010 capped cylinder, 300X110 mm.
- Reducing the shielded volume reduces the wall thickness. Halving the shield height has a big impact on performance.
- As discussed with Craig, dimensions will be finalized when/if the shields are engineered. Need to take account of backing line connection and cooling.



Turbo Shield Concept



Installation






The two halves can be held together by steel bands. The gap can be controlled by a thin gauge during assembly, should not be much bigger than 0.1 mm.





Turbo Shield Performance

- Applied uniform field using window-frame magnet option in Opera.
- The field inside the shielded area is below the 5 mT limit
- The 220mm "safe" area can be extended further by 3-4 cm by a adding chimney.



The vacuum gauge shield






The same cylinder as used for the pump, only 200 mm long



Vacuum Gauge Shield Performance

- The field inside the shielded area is well below 5 mT. The acceptable limit is 10 mT
- The 140 mm "safe" area is more than sufficient as the gauge itself is ~100 mm long.



Turbo & Gauge Shield Summary and further work

- Turbo pump shield surpasses the design specification of an internal field lower than 5mT, regardless of direction.
- The shield is ~8 kg, with a wall thickness of 10 mm.
- Shielding design for vacuum gauge is similar and straightforward
- 75% of the work on the cryostat shielding is now complete (PSU, pump and vacuum gauge)
- Cold head shield started, detailed material breakdown known
- Need to look at magnetic forces on all shielding items as this will inform engineering detail. Need to identify engineering effort

- Plan to move lid heater box. Require longer thermocouples and lid heater element. Main issue is cassette pressure gauge
- Also source pneumatic power cut-off valve for insulating vac
- Have shielding cans for 1553 transformer on AFE PCB





Integration Engineering update

Jason Tarrant

- Move Equipment in Areas of High Risk
- Compressors feeding cold heads originally located under south mezz were in high magnetic field and required move to west wall.
- Rack Room 2 (north shield wall alternative)

JT Partial Return Yoke Engineering (Holger to cover this)



Existing West Wall



West wall mezzanine will be this level

Existing high power cable to be moved



PPS system trunking


Services to be moved or bridged by the west mezzanine




Platform, Compressor & Services



19 Compressors for Step IV + 12 for Steps V & VI in stands



Cable trays for compressor hoses & power cables from first floor compressors



Hose and cable tidy along south mezzanine corridor

Cable trays for compressor hoses & power cables from ground floor compressors



West Wall Compressor Move



- What (Completion Date)
 - Distribution board move (March 2013)
 - Design, structural engineering and approval (May 2013)
 - South west air-con & supply services (June 2013)
 - Auxiliary equipment crane move (June 2013)
 - Mezzanine platform build on west wall of MICE Hall (Sep 2013)
 - Water services, including water plant relocation (Sep 2013)
 - Services installation & management (Jan 2014)
 - Some related infrastructure changes(Jan 2014)
 - Lighting
 - PPS
 - Power cables
 - Compressor stands with integrated power (Feb 2014)
 - Compressor & services installation and ready to run (April 2014)

Rack Room 2



Why

- Same magnetic field problem as compressors but longer cable & services length available. Move out of the MICE Hall to new Rack Room 2 (RR2) was a logical step.
- Allows operational changes and debug without breaking PPS or disrupting running.


Requirements

- Capacity in RR2 to eventually house all racks for Step VI
- Minimal change to building form as will be returned to ISIS
- Fire safe, including services runs
- Climate controlled space
- Provide safe and easy access to racks



RR2 & MLCR Reconfiguration





Rack Room 2



- What (Completion Date)
 - Asbestos removal work (May 2013)
 - Design, structural engineering & approval (July 2013)
 - Cable ways through walls and cable management (Aug 2013)
 - Building (doors, apertures, walls) (Nov 2013)
 - Air management & temperature control (Jan 2014)
 - Install services, power distribution & electrical (Jan 2014)
 - False Flooring (rack room and main walkway) & cable trays (March 2014)
 - Rack installation and ready to run (May 2014)







Delivery, Assembly & Handling




Floor plan showing legs of platform and room for delivery and assembly area of the MICE experimental devices





SS in lifting position with tandem lifting frame





Summary

Three different strategies for improving shield performance have been considered:

Adding a second layer of mu-metal to the steel?

Does not work at flux density levels typical for the MICE shielding problem.

Adding steel only where the flux density is higher?

Works. Allows corrections to be made at a later stage

Using co-axial cylinders with gaps (quasi-zero-gauss chambers)?

Works. Could be implemented, if needed.

