

Development of a low-pressure helium compression control strategy for CMTF

Ruslan Nagimov, BMSTU/E4

Supervisors: Arkadiy Klebaner, Jay Theilacker
FNAL/AD/ENG/CRYO

Summer students meeting, PARTI Program, FNAL
August 29, 2012

Fermilab Cryomodule Test Facility

Fermilab Cryomodule Test Facility (CMTF) provides a test bed to measure the performance of cryomodules and SRF cavities for future accelerators (Project X, ILC, Muon Collider).




CMTF Refrigerator

- Must be capable to operate efficiently over a wide range of heat loads.
- Will be more energy efficient than any superfluid helium cryogenic system currently in operation in Fermilab.
- It is being designed as a one-size-fits-many cryogenic plant for the laboratory's future research projects.



The Key is the Hybrid Cryogenic Cycle

- Use both warm and cold compression
- Efficient cryogenic capacity turndown is accomplished by adjusting a cryogenic system helium mass flow rate to match the heat load generated by SRF components.



Cold & Warm Compressors

Why Cold Compressors?



- Cold pumping allows recuperate cold before helium re-cooling → **increasing overall efficiency**
- The cold helium has a higher density → **decreasing number of compression stages**
- A compressor stage can have characteristics corresponding to optimal helium suction conditions → **increasing adiabatic efficiency**

Why Not Only Cold Compressors?



- Cold compressor set has the fixed pressure ratio → **decreasing working mass flow range**
- Limited turndown capability → **decreasing efficiency**

Cold & Hybrid Cycles Comparison

Multistage cold compressors –
“cold” compression cycle




Cold compressors in series with
warm compressor – “hybrid” cycle




Mass Flow Rate Reduction Capability

“Cold” cycle:
pressure ratio \approx const



“Hybrid” cycle:
pressure ratio is variable



$$Q = M \times H_{\text{vap}}$$

Q – Heat Load; M – Mass Flow Rate; H_{vap} – Heat of Vaporization

“Cold” cycle ($T_{\text{He}} = 2.0 \text{ K}$):

$M/M_{\text{design}} = 75\% \dots 100\%$

$Q/Q_{\text{design}} = 75\% \dots 100\%$


“Hybrid” cycle ($T_{\text{He}} = 2.0 \text{ K}$):

$M/M_{\text{design}} = 50\% \dots 100\%$


$Q/Q_{\text{design}} = 50\% \dots 100\%$

Temperature Level Adjusting Capability

“Cold” cycle:



“Hybrid” cycle:



Conclusions

“Cold” cycle

- Using only cold compressors
- Easier to operate
- Limited capability
 - Single temperature level
 - Limited heat load range
- Requires use of resistive heating for operation in off-design mode

“Hybrid” cycle

- High dynamic range
 - Various temperature levels
 - Various heat load
- High efficiency in off-design mode without resistive heating
- Using volumetric machine
- Complex control system

Goals & Perspectives

- ✓ Develop cold compressor units control system strategy.
- ✓ Develop common control system strategy including cold compressor units and warm vacuum pump.
- ✓ Optimize control system strategy.
- ✓ Compare characteristics of cold and hybrid cycles using models of compression process.
- ❑ Develop static and dynamic models of coldbox including cold compressors, warm vacuum pump, heat exchangers and another equipment.
- ❑ Write a technical note.